



Installation manual

EN

SPANNTOP [nova]

- combi pull-back
- combi deadlength
- modular

Table of contents

1	General.....	5
1.1	Information about this manual.....	5
1.2	Description of variants.....	5
1.3	Explanation of symbols.....	6
1.4	Limitations of liability.....	7
1.5	Balance quality.....	7
1.6	Max. RPM.....	8
1.7	Copyright.....	8
1.8	Scope of delivery.....	8
1.9	Spare parts.....	9
1.10	Warranty terms.....	9
1.11	CFK.....	9
2	Safety.....	10
2.1	Responsibility of the customer.....	10
2.2	Personnel requirements.....	11
2.3	Intended use.....	12
2.4	Personal protective equipment.....	13
2.5	Special dangers.....	14
2.6	Further warnings.....	17
2.7	Clamping force.....	18
2.8	Screws.....	19
2.9	Functionality.....	19
2.10	Implementation limits.....	19
2.10.1	Nomenclature.....	20
2.10.2	First limit [workpiece length].....	21
2.10.3	Second limit [workpiece mass].....	21
2.10.4	Third limit [clamping length].....	22
2.10.5	Fourth limit [forces].....	23
2.10.6	Sample calculation.....	34
2.11	Environmental protection.....	38
3	Technical data.....	39
3.1	General Information.....	39
3.2	Clamping force diagram.....	43
3.2.1	Clamping force diagram – size 32.....	44
3.2.2	Clamping force diagram – size 42/52.....	45
3.2.3	Clamping force diagram – size 65/80.....	46
3.2.4	Clamping force diagram – size 100/125.....	47
3.2.5	Clamping force diagram – size 140/160.....	48
3.3	Operating conditions.....	49
3.4	Power specifications.....	49
3.5	Type designation.....	49
4	Structure and function.....	50
4.1	Overview and brief description of the SPANNTOP [nova] combi pull-back	50

4.2	Overview and brief description of the SPANNTOP [nova] combi deadlength	52
4.3	Overview and brief description of the SPANNTOP [nova] modular.....	54
4.4	Optional Accessories.....	55
4.4.1	Standard end-stop.....	55
4.4.2	Workpiece end-stop.....	56
4.4.3	Clamping head RD.....	56
4.4.4	Changing fixture.....	56
4.4.5	Threaded adapter.....	57
4.4.6	Drawtube adapter.....	57
4.4.7	Reducing coupling.....	57
4.4.8	Assembly wrench.....	57
4.4.9	MANDO Adapt T211/T212.....	58
4.4.10	Jaw module.....	58
4.4.11	Magnet module.....	59
4.4.12	Grease.....	59
5	Transporting, packaging and storing.....	60
5.1	Safety instructions for transporting.....	60
5.2	Symbols on the packaging.....	60
5.3	Transport inspection.....	61
5.4	Unpacking and inner-company transportation.....	61
5.5	Packaging.....	62
5.6	Storing.....	63
6	Assembly.....	64
6.1	Pre-consideration.....	64
6.2	Preparations.....	65
6.2.1	Preparing SPANNTOP nova combi deadlength and SPANNTOP nova combi pull-back clamping devices.....	65
6.2.2	Preparing the SPANNTOP nova modular clamping device.....	66
6.3	Installation.....	67
6.3.1	Assembling the flange [optional].....	69
6.3.2	Adjusting the concentricity of the spindle flange.....	70
6.3.3	Checking face run and concentricity.....	71
6.3.4	Installing the SPANNTOP [nova] combi deadlength or SPANNTOP [nova] combi pull-back clamping unit size 32-120.....	72
6.3.5	Installing the SPANNTOP [nova] combi deadlength or SPANNTOP [nova] combi pull-back clamping unit size 125-160.....	74
6.3.6	Assembly of the SPANNTOP [nova] modular.....	76
6.3.7	Checking and adjusting the face run and concentricity of the clamping unit.....	79
6.3.8	Assembly of the clamping device to an interface.....	80
6.3.9	SPANNTOP [nova] modular – reduction of the size.....	80
6.3.10	Installing the base end-stop.....	81
6.3.11	Assemble the clamping head.....	82
6.3.12	Assembly of the workpiece end-stop.....	83
6.4	Workpiece.....	84
6.5	Inspections.....	85
6.6	Control of the stroke position.....	86
6.7	Activities after production is concluded.....	86

7	Disassembly.....	87
7.1	Safety.....	87
7.2	Disassembly of the workpiece end-stop.....	88
7.3	Disassemble the clamping head.....	89
7.4	Disassembling the base end-stop.....	89
7.5	Disassembly of the clamping device from an interface.....	90
7.6	Disassembling the clamping unit SPANNTOP [nova] combi deadlength and SPANNTOP [nova] combi pull-back size 32-120.....	91
7.7	Disassembling the clamping unit SPANNTOP [nova] combi deadlength and SPANNTOP [nova] combi pull-back size 125-160.....	92
7.8	Disassembling the SPANNTOP nova modular clamping unit.....	95
7.9	Disassembling the spindle flange.....	96
7.10	Subsequent storage of the clamping device.....	97
7.11	Disposal.....	97
8	Maintenance.....	98
8.1	General.....	98
8.2	Cleaning.....	99
8.3	Preservation.....	100
8.4	Use of lubricant.....	101
8.5	Maintenance schedule.....	102
8.6	Bolt torque.....	103
9	Trouble shooting.....	104
9.1	Safety.....	104
9.2	Trouble shooting table.....	105
9.3	Start-up after corrected fault.....	106
10	Appendix.....	107
10.1	Service Hotline.....	107
10.2	Representatives.....	107
	Index.....	108
	Manufacturers declaration.....	111

1 General

1.1 Information about this manual

This manual enables safe and efficient handling of the clamping device.

The manual is a component of the clamping device and must be kept in the immediate vicinity of the clamping device where it is accessible for personnel at all times. Personnel must have carefully read and understood this manual prior to starting all tasks. The basic prerequisite for safe work is compliance with all the safety instructions and handling instructions in this manual.

Illustrations in this manual are provided for a basic understanding and may deviate from the actual model of the clamping device.

It is assumed that the reader is familiar with standard procedures, such as cleaning the mounting surfaces.

1.2 Description of variants

Three variants of the SPANNTOP [nova] clamping device are presented in this manual:

- SPANNTOP [nova] combi pull-back
- SPANNTOP [nova] combi deadlength
- SPANNTOP [nova] modular

If the variants differ in structure, installation, disassembling and maintenance or fault correction, they will be described separately.

Based on the headers, sections and action steps can always be assigned to a specific variant.

Starting with weight 15 kg suitable tools must be used to transport the clamping device.

1.3 Explanation of symbols

Safety instructions

Safety instructions are indicated by symbols in this operating manual. The safety instructions are introduced by signal words that express the scope of the hazard.

The safety instructions must be strictly adhered to. You must act prudently to prevent accidents, personal injury, and material damage.



DANGER

... indicates an imminent dangerous situation that can result in death or serious injury if it is not avoided.



WARNING

... indicates a possible dangerous situation that can result in death or serious injury if it is not avoided.



CAUTION

... indicates a possible dangerous situation that can result in minor or light injury if it is not avoided.



NOTE

... indicates a possible dangerous situation that can result in material damage if it is not avoided.

Tips and recommendations



... indicates useful tips and recommendations, as well as information for efficient and trouble-free operation.



... indicates important tips and recommendations to further documents for safe operation.

1.4 Limitations of liability

All information and instructions in this operating manual have been provided under due consideration of applicable standards and regulations, the current state of technology, as well as our many years of experience.

The manufacturer assumes no liability for damage due to:

- Failure to follow the instructions in the manual
- Non-intended use
- Deployment of untrained personnel
- Unauthorized conversions
- Technical changes
- Use of non-approved spare parts
- Use of non-approved accessories

The actual scope of delivery can vary from the explanations and graphic representations provided in this manual in the case of special versions, if supplemental order options are desired, or on the basis of the latest technical changes.

The agreed obligations in the delivery contract, the general terms and conditions, as well as delivery conditions of the manufacturer, and the statutory regulations valid at the time the contract was concluded, apply.

1.5 Balance quality



CAUTION!

Our clamping devices are balanced with balance quality $G = 4$, in one level $n = 1$.

The data on the rotation balance refers to rotationally symmetrical workpieces.

The clamping of not rotationally symmetrical workpieces may not be clamped and/or only be clamped after consultation with the manufacturer.

Balancing bolts and balancing weights at the clamping devices may not be removed / disassembled!

1.6 Max. RPM



CAUTION!

The maximum permissible speed is marked on the product.

By the combination of a clamping device and an add on clamping device a reduction of the maximum permissible speed may be necessary.

- Of all RPMs of the groups specified, the **lowest given RPM** must always be used.

Note that the clamping force is influenced by the centrifugal force of the clamping elements.

- If necessary, adjust the machining force!

1.7 Copyright

This manual is protected by copyright and is provided exclusively for internal purposes.

Delivery of the operating manual to third parties, duplication in any form – including excerpts – as well as exploitation and/or communication of the content, are not permitted [except for internal use] without written approval from the manufacturer.

Actions to the contrary make damage compensation mandatory. We reserve the right to enforce additional claims.

1.8 Scope of delivery



All tools and accessories that are not included in the scope of delivery are marked as optional.

In scope of delivery of the clamping device:

- 1 Spindle flange
- 1 Clamping unit
- 1 Base end-stop

Optionally the scope of delivery of the clamping device includes:

- Eye bolts
- 1 Threaded adapter

1.9 Spare parts



WARNING!

Safety risk if the wrong spare parts are used!

Incorrect or defective spare parts can cause damage, malfunction, or total failure; they can also impair safety.

- Only use manufacturer's original spare parts.

Only purchase spare parts from authorized dealers or direct from the manufacturer. Addresses are in the appendix.

1.10 Warranty terms

The warranty terms are included in the manufacturer's terms and conditions.

1.11 CFK



In case of visible damage or visible wear of the carbon parts:

- Further processing only after consultation with HAINBUCH.

2 Safety

This section provides an overview of all the important safety aspects for optimal protection of personnel, as well as for safe and trouble-free operation.

2.1 Responsibility of the customer

The product is used in industrial applications. Consequently the owner of the product is subject to legal industrial safety obligations.

In addition to the safety instruction in this manual, generally valid safety and accident protection guidelines, and environmental protection guidelines as well as the machines' manual must be adhered to and complied with for the area of implementation of the device.

Note in particular that the status scans of the machine must be adjusted to the respective product.



DANGER!

Risk of injury due to thrown out parts!

Incorrect machine settings may lead to the throwing out of parts.

- The status scans the machine must be set to the respective clamping device.
- Regularly check the status scans of the machine, see chapter »Maintenance Schedule«. If the end position can not be reached the product may no longer be used.
- Observe the operating instructions of the machine.



WARNING!

Risk of injury!

Declining operating force, for example by declining energy supply, may cause serious personal injury.

- The product may be used only on machines where it is ensured, that during use, the operating force does not drop.



WARNING!

Risk of injury!

An incorrect media supply [hydraulic, pneumatic], e.g. by damaged or missing seals or pipes, can cause serious personal injury.

- Hydraulic and / or pneumatic tubes must be secured by the machine by check valves and a permanent pressure monitoring!

2.2 Personnel requirements



WARNING!

Danger of injury due to insufficient qualification!

Improper handling of the clamping device can cause serious injury or material damage.

- Only have activities performed by personnel who are qualified to perform these activities.

The following qualifications are cited in the operating manual for the various activity areas.

■ **Specialized personnel**

are personnel who due to their specialized training, skills, and experience, as well as knowledge of the applicable regulations, are capable of executing the tasks assigned to them and of recognizing and avoiding possible hazards on their own.

■ **Hydraulic specialist**

The hydraulic specialist has been trained for the particular task area in which he is active and is familiar with the relevant standards and regulations. Due to his specialized training and experience the hydraulic specialist can perform tasks on hydraulic equipment and recognize and avoid possible dangers on his own.

■ Electric specialist

The electric specialist has been trained for the particular task area in which he is active and is familiar with the relevant standards and regulations.

Due to his specialized training and experience the electric specialist can perform tasks on electric equipment and recognize and avoid possible dangers on his own.

Only persons from whom it can be expected that they reliably execute their work are considered as personnel. Persons whose capability to react is impaired, for instance through drugs, alcohol, or medication, are not approved.

- Comply with age-specific and job-specific regulations that are applicable at the installation site when selecting personnel.

2.3 Intended use

The clamping device is designed for installation in a machine tool according to CE compliant. Within the machine tool the clamping device is designed exclusively as a through-bore chuck for bar work and / or as an end-stop chuck for chuck work.

The clamping device should only be mounted, operated, maintained, and cleaned by instructed, specialized personnel.

Intended use also includes compliance with all the instructions in this manual.

The clamping device is to be used for the case of application contractually agreed between the producer/deliverer and the user, as well as such cases of application described in the product description which are also in accordance with the technical values.

The safe function of the clamping device is, as far as it can be foreseen, guaranteed when it is used for the intended purpose in accordance with the appropriate safety regulations.

Any use that extends beyond the intended use, or any other use of the clamping device is considered to be misuse and can cause dangerous situations.



WARNING!

Danger due to misuse!

Misuse of the clamping device can cause dangerous situations.

Particularly refrain from the following uses of the clamping device:

- Use in machines other than machine tools.
- Use in machine tools with technical data other than that specified on the clamping device.

Claims of any type due to damage arising from non-intended use are excluded.

Unintended and improper use of the Power Chuck is for example

- If workpieces are not clamped properly
- If safety regulations are disregarded and persons are working at the clamping device without additional protective devices e.g. for machining.
- If the clamping device is used for machines or tools for which it is not intended.

2.4 Personal protective equipment

Wearing of personal protective equipment is required to minimize health hazards when working with the device.

- Always wear the protective equipment necessary for the respective task when working with the device.
- Follow the instructions that have been posted in the work area.

Always wear



For all tasks always wear:

Protective work clothing

is tight-fitting work clothing with low resistance to tearing, with tight sleeves, and without projecting parts. It is primarily used to protect against entanglement by moving machine parts.

Do not wear rings, chains, or other jewelry.



Safety footwear

for protection against heavy falling parts and slipping on slippery substrates.

For special tasks wear



Special protective equipment is required when executing special tasks. Separate reference is made to this equipment in the specific sections of this manual. This special protective equipment is explained below:

Hard hat

to protect against falling and flying parts and materials.

Protective goggles

to protect eyes from flying parts and liquid splashes.

Protective gloves

to protect hands from friction, abrasion, puncture wounds, or deeper injuries, as well as from contact with hot surfaces.

Haarnetz

zum Schutz der Haare vor Erfassung durch die rotierenden Teile der Maschine.

2.5 Special dangers

In the following section residual risks are cited that occur due to installation of the clamping device in a machine tool. In each case the residual risks that have been determined based on a risk analysis of the machine must be specified by the customer.

- Follow the safety instructions listed here and the warnings in the other sections of this manual to reduce health hazards and to avoid dangerous situations.

Horizontal / lying parts



WARNING!

Danger of injury due to horizontal parts!

Before transporting the clamping device in horizontal condition:

- Put the clamping device on a non-slip pad.
- Screw in the eye bolts.

Suspended loads



WARNING!

Life-threatening danger due to suspended loads!

Clamping device with weight more than 15 kg must be lifted with a crane. When lifting the clamping device there is a life-threatening hazard due to falling parts or parts swinging out of control.

- Never step under suspended loads.
- Comply with the instructions concerning the intended attachment points. Ensure that the sling gear is securely seated!
- Do not attach lifting gear in projecting components.
- Only use approved hoists and sling gear with sufficient bearing capacity.
- Do not use rope and belts that are torn or frayed.

Moving parts



WARNING!

Danger of injury due to moving parts!

Rotating parts of the clamping device can cause serious injuries.

- Do not reach into moving parts or handle moving parts during operation.
- Pay attention to the clearance of moving parts.
- Do not open covers when the device is in operation.
- Be aware of afterrun time:
- Prior to opening the covers ensure that all parts have come to a standstill.
- Wear tight-fitting protective work clothing in the danger zone.

Wrong clamping of the workpiece



WARNING!

Danger of injury due to incorrect clamping of the workpiece!

Incorrect workpiece clamping may lead to the ejection of the workpiece and result in serious injuries.

Under dimensioned parts can lead to incorrect clamping!

- Check the unmachined workpieces at random on dimensional accuracy.

Too low axial clamping force can lead to the reduction of clamping force!

Too high axial clamping force can lead to damage of the components of the clamping device!

- Check and adjust, if necessary, the axial clamping force regularly.

Missing changing parts



WARNING!

Danger of injury due to missing changing parts!

When operating the clamping device without changing parts [clamping heads, work piece end-stops] there is a higher danger of crushing injuries due to the stroke of movable components of the clamping device.

- The clamping process may not be initiated without assembled segmented clamping bushing and/or work piece end-stop.

Parts with sharp edges



WARNING!

Risk of injury!

When screwing in individual components such as for example work piece end-stops, threaded adapters and similar devices that are equipped with an external thread or wear caused by burrs, there is risk of cutting.

- The operation must be done only by qualified personnel.
- Wearing of gloves / [PSA / personal protective equipment] is required!



CAUTION!

Risk of injury!

A special use-dependent or job-based design can result in variations in the clamping strokes and thus the clamping force.

- The notes on the associated clamping situations or product drawing must always be observed

2.6 Further warnings



WARNING!

Risk of injury!

Never reach for the clamping device while the spindle is rotating. Before starting to work on the clamping device, make sure the machine spindle cannot be put in motion.




Fig. 1



CAUTION!

Risk of injury through slots and / or holes!

The clamping device can be provided with large slots and/or holes [e.g. chips drain holes].

- **Never** reach into the slots and/or holes, either during assembly / disassembly as well as during machining.



WARNING!

Risk of injury!

Falling down of the clamping device or its parts can cause severe bruises and fractures.

The dead weight of the clamping device or its parts can lead to high physical stress.

- Always wear safety shoes.
- From weight 15 kg always use a suitable transport trolley.



WARNING!

Risk of injury!

By repeated reworking or wear and tear of the clamping surfaces sharp edges and burrs may appear and lead to severe cutting damages.

- Remove any burr.
- If necessary, replace worn parts with original HAINBUCH spare parts.



WARNING!

Risk of injury!

Escaping [sprayed out] hydraulic oil from adjacent machine components can cause serious personal injuries.

- Make sure that all O-rings / seals for the hydraulic and/or pneumatic connections are available and undamaged!



WARNING!

Damage of clamping device!

The clamping device may be released exclusively in the non-rotating condition!

2.7 Clamping force

The achieved clamping force can vary due to the maintenance condition of the clamping device [state of lubrication and degree of contamination] [see chapter »Maintenance«].

The clamping force must be checked at regular intervals. This requires the use of static clamping force measuring devices.



CAUTION!

Damages due to excessive draw and compressive force!

An excessive draw force and/or compressive force may damage the clamping device and/or the drawtube adapter.

- The max. draw force and compressive force may not be exceeded.

2.8 Screws

Moving parts



WARNING!

Danger of injury due to screws and stud screws being accelerated out of the device!!

Screws and stud screws radially attached to the product can be accelerated out of the device and cause severe injuries.

- At the product radially mounted screws and stud screws which were loosened for assembly and maintenance must be re-tightened with the correct tightening torque!
The tightening torque is given at the product itself, near the screw or threaded pin, and/or given in chapter »Bolt torque«.
- All screws or stud screws that are not marked with a tightening torque specification are tightened with the prescribed tightening torque and locked [medium-strength bonding] in the factory and should only be unscrewed after consultation with the manufacturer. If in doubt you must contact the manufacturer immediately to determine the subsequent procedure.

2.9 Functionality



NOTICE!

With high contamination of the clamping device the functionality is no longer guaranteed.

- The cleaning and maintenance intervals must be observed.

2.10 Implementation limits

Clamping head chucks are designed and developed for location of workpieces for machining of rotationally-symmetric workpieces. Other fields of application require an explicit approval by the manufacturer.

The chucks are also subject to limits in the area of machining of workpieces.

Specifically, prior to using the chucks, four limits that are independent of each other must be checked.

2.10.1 Nomenclature

Short description	Unit	Explanation
a_p	mm	Depth of cut, turning operation
c	-	Contact factor
D_B	mm	Drill bit diameter
d_{sp}	mm	Clamping diameter
d_z	mm	Machining \varnothing turning operation
f	mm	Feed / turn turning operation Feed / cutting edge drilling operation
F_B	N	Feed force, drilling operation
F_c	N	Cutting force, turning operation
$F_c \text{ max}$	N	Max. cutting force, turning operation
F_{fz}	N	Clamping force contingency for rotation compensation
F_G	N	Weight force, workpiece
f_n	mm	Feed / turn drilling operation
F_q	N	Transverse force
$F_q \text{ max}$	N	Max. permissible transverse force
F_{rad}	N	Radial clamping force
F_{raderf}	N	Required radial clamping force
F_{sk}	N	Clamping force for preventing the workpiece from levering out
F_{sz}	N	Clamping force for location of the machining forces and machining moments when turning or drilling in the direction of the chuck axis
F_t	kN	Tailstock force
$F_t \text{ max.}$	kN	Max. tailstock force
kc	N/mm ²	Specific cutting force
L_a	mm	Unclamping length
L_g	mm	Distance, center of gravity - workpiece - clamping position
L_q	mm	Distance: "radial drilling – clamping position"
L_{sp}	mm	Clamping length
L_{spmin}	mm	Minimum required clamping length
L_w	mm	Workpiece length
L_z	mm	Distance: »machining point – clamping position« when turning
m	kg	Mass of the clamping head
m_w	kg	Workpiece mass
M_B	Nmm	Torque, drilling operation

Short description	Unit	Explanation
Mq	Nm	Moment due transverse force relative to the chuck axis
Mqmax	Nm	Max. moment due to transverse force relative to the chuck axis
n	1/min	Speed
p	-	Machining code
rs	mm	Distance center of mass SK segment relative to the axis of rotation of the chuck
S	-	Clamping force spread factor
μ_a	-	Coefficient of friction in the axial direction
μ_t	-	Coefficient of friction in the radial direction

The following sketch is provided for graphic illustration of the forces and torques used below in the calculating examples:




Fig. 2

2.10.2 First limit [workpiece length]

The max. unclamping length that can be machined without the aid of steady rest or tailstock is specified at max. 6x the clamping diameter.

2.10.3 Second limit [workpiece mass]

The maximum workpiece mass depends on the chuck size and is shown in Table 1. [Values apply for individual workpieces; separate limit values apply for bar work]

Chuck size	Max. workpiece mass [m_w /kg]	
	Horizontal use	Vertical use
32	12	18
42	20	30
52	28	40
65	40	60
80	50	75
100	65	100
125	80	120
140	100	150
160	120	180

Table 1: Maximum workpiece mass

2.10.4 Third limit [clamping length]

Minimum clamping length within the chuck taper $L_{sp, min}$.



CAUTION

In this regard clamping head extension lengths remain completely unconsidered].



CAUTION

With offset clamping holes [counter bore], any undercut at the clamping head has to be considered when determining the clamping length.

General $L_{sp} \geq 0.08 \cdot d_{sp}$




Fig. 3

Moreover, the following also applies:

$L_{sp} \geq 2,8 \text{ mm}$ [Use of clamping heads with smooth clamping bore]

$L_{sp} \geq 13 \text{ mm}$ [Use of clamping heads with longitudinal and radial grooves]¹

$L_{sp} \geq 7 \text{ mm}$ [Use of clamping heads with Z-serration]

$L_{sp} \geq 5 \text{ mm}$ [Use of clamping heads with F-serration]

¹ Values that deviate from the above apply for use of clamping heads with a closed first duct; these values could even be higher. If required these values must be requested from the manufacturer.

2.10.5 Fourth limit [forces]

The forces acting on the workpiece from the outside. Determination of these forces is explained in the following calculation approach.

In this regard it must be determined whether

1. the clamping force necessary for absorbing the external forces and torques, can be applied through the clamping device.
2. the clamping device is damaged visibly or in a manner that is not apparent through the external forces.

The forces and moments acting on the clamping element [clamping head] and ultimately on the clamping device [chuck] are essentially

- a) Machining forces and machining moments that must be absorbed
- b) The weight force of the workpiece itself,
- c) Centrifugal forces due to the weight of the clamping head
- d) Tailstock forces

Principles for the forces acting on the workpiece from the outside



NOTE!

For safe machining², the following must apply at all times:

1st principle $F_{rad} \geq F_{raderf}$

AND

2nd principle $F_t \leq F_{t_{max}}$

AND

3rd principle $F_c \leq F_{c_{max}}$

[relevant for turning jobs or axial drilling operation]

AND

4th principle $F_q \leq F_{q_{max}}$
[relevant for drill operation, radial and directed to the center and/or for an equivalent³ load]

UND

5th principle $M_q \leq M_{q_{max}}$
[relevant for drill operation, radial and directed to the center and/or for an equivalent³ load]

2.10.5.1 For principle 1: $F_{rad} \geq F_{raderf}$

Determination of the required clamping force

Determination of the required clamping force F_{raderf} at speed

The equations apply for longitudinal turning operations as well as face turning operations. Drilling operations on the face of the workpieces can also be calculated. Overlaid, simultaneous processing, e.g. through multiple tools or turrets, must also be mathematically overlaid, i.e. the required radial clamping forces of the individual machining procedures must be added.

However axial drilling and turning jobs are rarely overlaid; because as a rule, they cannot run simultaneously, due to opposite directions of rotation.

2 With these principles it is assumed that the chuck is used for turning jobs or for axial or radial drill operation on the workpiece. The possibility that the chuck can also be used for other machining tasks, such as peripheral milling or plunge milling, is not fundamentally excluded. However, in this regard the user must ensure that the forces and moments occurring in the process are compared with the permissible equivalent values of a turning process or drilling process in order to verify the permissibility of the application.

3 If the radial forces and the resulting moments are not directed towards the center, this can be considered by a quasi cutting force outside the center.

For the calculation, the point with the highest forces, i.e. the most unfavorable torque of the machining, must serve as the mathematical basis. If in doubt, a check of multiple cutting edge engagement situations is required to determine the most unfavorable.

If radial drilling operations are undertaken, in addition to determination of the required, radial clamping force $F_{\text{rad erf}}$, primarily verification of the introduced transverse force F_q and the resulting moment M_q also play a central role.

Spread of the clamping force

Chuck size SPANNTOP	Radial clamping reserve in diameter [mm]	Clamping force spread factor S ⁴	Clamping force spread factor S »verified« ⁵
32	1,0	2,8 ⁶	1,3
42	1,0	2,0 ⁶	1,3
52	1,0	2,0 ⁶	1,3
65	1,0	1,6 ⁶	1,3
80	1,0	1,6 ⁶	1,3
100	1,5	1,45	1,3
125	2,5	1,45	1,3
140	1,5	1,45	1,3
160	1,5	1,45	1,3

Table 2: Spread of the clamping force

- 4 These values are based on a regularly maintained and lubricated operating status as specified in the operating manual.
- 5 If the radial clamping force is measured before each commissioning, and continuously every 100 clamping set-ups, with a measuring device that is suitable for this purpose, then work can be performed with the reduced clamping force spread factor shown.
- 6 If due to more dimensionally accurate workpieces the radial clamping reserve of the chuck [see Table 2] is only utilized up to a limit of 50%, the clamping force spread factor can be reduced by a factor of 0.85 [example:

Forms of contact




Fig. 4: Forms of contact between smooth top jaws and workpiece

Contact case

- Snug fit** The clamping diameter of the clamping head is equal to the clamping diameter on the workpiece.
- Saddle seat** The clamping diameter of the clamping head is greater than the clamping diameter on the workpiece.
- Edge seat** The clamping diameter of the clamping head is less than the clamping diameter on the workpiece.

Contact factor c	Machining conditions	Snug fit and saddle seat	Edge seat
Smooth clamping head	Dry	1,1	1,0
	Wet or MMS ⁷	1,3	1,2
Clamping head with longitudinal or transverse serration	Dry	1,1	1,0
	Wet or MMS ⁷	1,3	1,2
Clamping head with Z-serration or F-serration	Dry	1,0	1,0
	Wet or MMS ⁷	1,2	1,1

Table 3: Contact factor

Specific cutting forces kc [N/mm²]

Corresponding to the relatively imprecise classification of the materials, these are guide values. Thus, in some cases greater deviations relative to the real values can be present.

For deviating workpiece materials, or for machining tasks in the limit area of the clamping device, the respective kc values of the material that will be machined must be precisely determined, or requested from the supplier of the material.

⁷ Wet machining MMS [MQL]:

Use of cooling lubricant [CLF]
Use of minimum quantity lubrication

Workpiece materials		Specific cutting forces k_c [N/mm ²] at $f=0,1\text{mm}$ ^{8,9,10}	Specific cutting forces k_c [N/mm ²] at $f=0,5\text{mm}$ ^{11,12}	Specific cutting forces k_c [N/mm ²] at $f=1,0\text{mm}$ ^{13,14}
Gray cast iron	e.g. EN-GJL-250	1980	1260	900
Nodular cast iron [unhardened]	e.g. EN-GJS-400-15	2120	1190	1060
Unalloyed/low-alloy construction steels [with average strength] / case-hardened steels [unhardened]	For example: S235JR [1.0037] S275JR [1.0044] Ck10 [1.1121] 16MnCr5 [1.7131] 18CrNi8 [1.5920]	2920	1840	1500
Unalloyed/low-alloy construction steels [unhardened, with high strength]	S355J2G3 [1.0570] E360 [1.0070]	3350	2000	1600
Heat-treated steels [prehardened]	C45 [1.0503] C60 [1.0601] 42CrMo4 [1.7225] 34CrNiMo6 [1.6582]	2850	1960	1660
Unalloyed/low-alloy tool steels [unhardened]	C105W1 [1.1545]	3100	2100	1690
Machining steels	35S20 [1.0726] 60S20 [1.0728]	1700	1480	1400
Stainless steels		3600	2450	2100
Hardened steels		4800		
Aluminum wrought-alloy <16%Si		1340	900	750
Aluminum cast-alloy <16%Si		1520	1000	850
Brass		1300	850	700

Table 4: Specific cutting forces k_c / [N/mm²]

- 8 For feeds, between 0.1 and 0.5 mm you must interpolate.
For feeds >0.5 mm, the values of column $f=0.5$ mm must be used.
- 9 For drilling operations with double-edged tools $f=f_n/2$ applies
- 10 For feeds, between 0.05 and 0.1 mm the value at $f=0.1$ with 20% contingency must be used.
- 11 For feeds, between 0.1 and 0.5 mm you must interpolate.
For feeds >0.5 mm, the values of column $f=0.5$ mm must be used.
- 12 For drilling operations with double-edged tools $f=f_n/2$ applies
- 13 For feeds, between 0.5 and 1.0 mm you must interpolate.
- 14 For drilling operations with double-edged tools $f=f_n/2$ applies

Coefficients of friction

For workpieces of a material other than steel, the values shown must be multiplied by the correction values specified below.

For hardened steel as the material, the values of the smooth clamping heads always apply for ground workpiece surfaces.



NOTE

Clamping of hardened materials or materials with extremely high strength values [$R_m > 1300 \text{ N/mm}^2$] is only permitted with clamping heads of the variants smooth, longitudinal or transverse serration!

Other clamping head designs can be damaged and lose their capacity of achieving higher coefficients of friction with soft materials.

Workpiece surface	Jaw clamping surface			
	Smooth clamping head	Clamping head with longitudinal and transverse serration	Clamping head with Z-serration	Clamping head with F-serration
Finely finished, ground	$\mu_t = 0,06$ $\mu_a = 0,08$	$\mu_t = 0,07$ $\mu_a = 0,09$	$\mu_t = 0,15$ $\mu_a = 0,20$	$\mu_t = 0,17$ $\mu_a = 0,22$
Finished to roughed	$\mu_t = 0,10$ $\mu_a = 0,13$	$\mu_t = 0,11$ $\mu_a = 0,15$	$\mu_t = 0,18$ $\mu_a = 0,25$	$\mu_t = 0,23$ $\mu_a = 0,28$
Rough machined or unmachined	$\mu_t = 0,14$ $\mu_a = 0,16$	$\mu_t = 0,16$ $\mu_a = 0,18$	$\mu_t = 0,20$ $\mu_a = 0,28$	$\mu_t = 0,25$ $\mu_a = 0,30$
Material correction values	Aluminum alloys = 0,97 Ms 58 = 0,92 GG-18 = 0,80			

Table 5: Friction coefficient for steel workpieces

SK mass m / [kg] and distance rs from the center of mass of clamping head segments to the axis of rotation / [m]		
Distance of center of mass rs in the smallest position		
SK size	rs / [m]	SK mass m / [kg]
32	0,015	0,51
42	0,021	1,00
52	0,022	1,02
65	0,027	2,05
80	0,032	2,50
100	0,045	3,85
125	0,061	8,60
140	0,062	8,70
160	0,072	11,8

Table 6: SK mass m / [kg] and distance rs from the center of mass of clamping head segments to the axis of rotation / [m]



S	From table 2
c	From table 3
kc	From table 4
μ_a, μ_t	From table 5
r_s, m	From table 6

I

$$F_{raderf} = S * c * (1,6 * (F_{sz} + F_{sk}) + F_{fz})$$



The factor 1.6 takes possible fluctuations in occurring force transmission into account.

II

$$F_{sz} = 1,3 * \sqrt{\left(\frac{F_c * d_z + 2M_B}{d_{sp} * \mu_t}\right)^2 + \left(\frac{F_c + F_B}{\mu_a}\right)^2}$$

Turning [inside & outside]

$$F_c = 1,3 * a_p * f * kc$$

Drilling

[full drilling, two-edged tool in the direction of the workpiece axis]

$$F_B = 0,45 * D_B * f_n * kc$$

$$M_B = \frac{f_n * D_B^2 * kc}{5700}$$

For calculation of the machining forces, a degree of blunting that corresponds to a wear mark width of 0.3 mm is taken into account.

III

$$F_{sk} = \frac{(0,27 * L_z / d_{sp} + 0,63) * \sqrt{(F_c * L_z + F_G * L_g)^2 + (F_c * p)^2}}{0,5 * (0,67 * (1,9 * L_{sp} - 4,5 \text{ m m}) + \mu_a * d_{sp})}$$

Longitudinal turning: $p = \frac{dz}{2}$

Face turning/plunging: $p = L_z$

If the workpiece is supported with a tail-stock, further calculation with 20% of the computed F_{sk} suffices.

IV

$$F_{fz} = (m * r_s) * \left(\frac{\pi * n}{30}\right)^2$$

In accordance with the principle defined above, this means that the radial clamping force of the chuck must at least equal the calculated, required radial clamping force F_{raderf} , in order to execute this machining task using the chuck.

If this condition is not satisfied, then the chuck is not suitable. The machining task must not be executed in this manner.

For clamping and machining of workpieces with greater concentricity errors and face runout, note that the clamping cross section fluctuates significantly. The resulting punctiform increase in the cutting force must be considered separately.

Radial drilling

For radial drilling operations, determination of the radial clamping force F_{raderf} likewise occurs in accordance with the approach

$$F_{raderf} = S * c * (1,6 * (F_{sz} + F_{sk}) + F_{fz})$$

however the components F_{sz} and $F_{fz}=0$ can be used, which results in a simplified form [pure transverse force]:

$$F_{raderf} = S * c * 1,6 * F_{sk}$$

For drilling that engages radially to the clamping device axis, determination of F_{sk} can be calculated similarly to formula III as follows:

$$F_{sk} = \frac{(0,27 * L_z / d_{sp} + 0,63) * (F_q * L_z + F_G * L_g)}{0,5 * (0,67 * (1,9 * L_{sp} - 4,5 \text{ m m}) + \mu_a * d_{sp})}$$

For calculation of F_q see section 2.10.5.4

$$F_q = F_B = 0,45 * D_B * f_n * k_c$$

2.10.5.2 For principle 2: $F_t \leq F_{tmax}$ ¹⁵

Tailstock force

Due to the additional spreading force on the chuck, the max. permissible tailstock force is limited to the following values in accordance with the chuck size:

Chuck size	F_{tmax} / [kN]
32	3
42	6
52	6
65	8
80	8
100	8
125	8
140	8
160	8

Table 7: Maximum permissible tailstock force

2.10.5.3 For principle 3: $F_c \leq F_{c max}$

The cutting force for turning operations can take on extremely high values, particularly with short projection lengths of the workpiece, although fundamentally processing without slip or levering out of the clamping set-up would still be possible. Consequently, this cutting force must also be limited in accordance with chuck size, to avoid chuck damage.

¹⁵ With use of a tailstock, by using an end-stop in the chuck, it must be ensured that the workpiece cannot be axially displaced.

Chuck size	Maximum chuck length [mm]	Fc max / [N]
32	< 120	1.900
42	< 125	3.600
52	< 125	3.600
65	< 140	5.000
80	< 140	6.000
100	< 160	8.000
125	< 200	12.000
140	< 200	12.500
160	< 200	14.000

Table 8: Maximum permissible cutting force

With extended chuck length, the maximum permissible cutting force must be reduced in the ratio of the feed lengths, e.g. size 32, L=150mm

$$\frac{120\text{mm}}{150\text{mm}} * 1900\text{N} = 1520\text{N}$$

2.10.5.4 For principle 4: $F_q \leq F_q \text{ max}$

For drilling tasks radial to the workpiece axis, due to the feed force of the tool, transverse forces occurs that ultimately act on the chuck. This load when drilling must be viewed as equivalent to the cutting force when turning, and consequently it must also be limited. The permissible maximum values are provided in the table below.

Occurring feed force F_B when drilling [transverse force]

[Full-drilling, two-edged tool, machining direction 90° transverse to the chuck axis]

$$F_q = F_B = 0,45 * D_B * f_n * k_c$$



k_c From table 4

Chuck size	Maximum chuck length [mm]	Fq max / [N]
32	< 120	2.200
42	< 125	4.200
52	< 125	4.200
65	< 140	6.000
80	< 140	7.200
100	< 160	9.000
125	< 200	13.000
140	< 200	13.800
160	< 200	15.000

Table 9: Maximum permissible transverse force

With extended chuck length, the maximum permissible cutting force must be reduced in the ratio of the feed lengths, e.g. size 32, L=150mm

$$\frac{120\text{mm}}{150\text{mm}} * 2200\text{N} = 1760\text{N}$$

2.10.5.5 For principle 5: $M_q \leq M_q \text{ max}$

For drilling tasks radial to the workpiece axis, the transverse force verified under principle 4 generates an additional torque M_q on the clamping head or on the chuck. This moment as well must not limitlessly increase without the chuck being damaged, although perhaps the clamping set-up would nonetheless still securely clamp the workpiece. Again, the table below shows the permissible maximum values.

Occurring torque M_q through introduction of the transverse force F_q

$$M_q = F_q * L_q$$

Chuck size	Maximum chuck length [mm]	Mq max [Nm]
32	< 120	120
42	< 125	210
52	< 125	210
65	< 140	300
80	< 140	360
100	< 160	450
125	< 200	650
140	< 200	690
160	< 200	750

Table 10: Maximum permissible moment Mq due to transverse force Fq

With extended chuck length, the maximum permissible cutting force must be reduced in the ratio of the feed lengths, e.g. size 32, L=150mm

$$\frac{120\text{mm}}{150\text{mm}} * 120\text{Nm} = 96\text{Nm}$$

2.10.6 Sample calculation

Applied to a specific example

Longitudinal turning of an offset shaft of 16MnCr5 [pre-machined clamping diameter] without tailstock support in horizontal position.

Workpiece data

- Clamping diameter $d_{sp} = 60 \text{ mm}$
- Workpiece length
 $L_w = 150\text{mm}$ [151,5mm unmachined]
- Machining diameter – turning operation
 $d_z = 57,0 \text{ mm}$
- Workpiece mass $m_w = 3,3 \text{ kg}$
 $\rightarrow F_G = m_w * 9,81 \text{ m/s}^2$
 $\rightarrow F_G = 33 \text{ N}$

Process data

- Speed $n=800 \text{ 1/min}$
- Feed $f=0,25 \text{ mm}$
- Clamping depth $a_p=1,5 \text{ mm}$
- Use of cooling lubricant
- Clamping length $L_{sp}=20\text{mm}$

Chuck

- SPANNTOP pull-back size 65

- Clamping head used:

D=60 mm, smooth, extension length=3 mm

Detailed consideration

The first condition, namely that the workpiece length may equal up to six times the clamping diameter, is satisfied.

The second condition, namely that the workpiece mass must not exceed 40 kg, at chuck size 65 is satisfied.

The third condition, that the workpiece must be clamped at least $0.08 \cdot d_{sp} = 0.08 \cdot 60 \text{ mm} = 4.8 \text{ mm}$, is more than satisfied with clamping length 20 mm – 3 mm extension length = 17 mm.

To verify the fourth condition, first it is necessary, in accordance with principle 1, to determine the required radial clamping force.



S	From table 2
c	From table 3
kc	From table 4 [interpolated for f=0,25]
μ_a, μ_t	From table 5
m, r_s	From table 6

$$F_{raderf} = S * c * (1,6 * (F_{sz} + F_{sk}) + F_{fz})$$

From table 2: S=1,6

From table 3: c=1,3

$$F_{raderf} = 1,6 * 1,3 * (1,6 * (F_{sz} + F_{sk}) + F_{fz})$$

$$F_{sz} = 1,3 * \sqrt{\left(\frac{(F_c * d_z + 2M_B)^2}{d_{sp} * \mu_t}\right) + \left(\frac{F_C + F_B}{\mu_a}\right)^2}$$

From table 5: $\mu_t = 0,14$
 $\mu_a = 0,16$

$$F_{sz} = 1,3 * \sqrt{\left(\frac{1226N * 57mm}{60mm * 0,14}\right)^2 + \left(\frac{1226N}{0,16}\right)^2} = 14.703 N$$

Turning:

$$F_C = 1,3 * 1,5 m m * 0,25 m m * 2515 \frac{N}{m m^2}$$

$$F_C = 1226N$$

Drilling:

Here not relevant, because drilling is not intended. Consequently

$$M_B = 0 \text{ Nm m}$$

$$F_B = 0 \text{ N}$$

$$F_{sk} = \frac{(0,27 * L_z / dsp + 0,63) * \sqrt{(F_c * L_z + F_G * L_g)^2 + (F_c * p)^2}}{0,5 * (0,67 * (1,9 * L_{sp} - 4,5 \text{ m m}) + \mu_a * dsp)}$$

$$F_{sk} = \frac{(0,27 * 133 \text{ mm} / 60 \text{ mm} + 0,63) * \sqrt{(1226 \text{ N} * 133 \text{ mm} + 33 \text{ N} * 75 \text{ mm})^2 + (1226 \text{ N} * 28,5 \text{ m m})^2}}{(0,5 * (0,67 * (1,9 * 17 \text{ mm} - 4,5 \text{ m m}) + 0,16 * 60 \text{ mm}))}$$

$$F_{sk} = \frac{207.838 \text{ Nm m}}{14,11 \text{ m m}} = 14.727 \text{ N}$$

$L_z = L_w = 133 \text{ mm}$, because the shaft on the front end should be longitudinally finished-turned.

$L_g = 75 \text{ mm}$, because the center of gravity is in the middle of the longitudinal workpiece axis.

$L_{sp} = 17 \text{ mm}$, corresponds to the full clamping length minus the extension length of the clamping head

$$p = \left(\frac{d_z}{2}\right) = \frac{57}{2} = 28,5$$

, because of longitudinal turning operation

$$F_{fz} = (m * rs + q) * \left(\frac{\pi * n}{30}\right)^2$$

From table 6: $m = 2,05 \text{ kg}$
 $rs = 0,027 \text{ m}$

$$F_{fz} = (2,05 \text{ kg} * 0,027 \text{ m}) * \left(\frac{\pi * 800 \frac{1}{\text{min}}}{30}\right)^2 = 390 \text{ N}$$

$$F_{raderf} = 1,6 * 1,3 * (1,6 * (F_{sz} + F_{sk}) + F_{fz})$$

$$F_{raderf} = 1,6 * 1,3 * (1,6 * (14.703 + 14.727) + 390) = 98.745 \text{ N}$$

$$F_{raderf} = 99 \text{ kN}$$

Because the size 65 chuck can apply a maximum radial clamping force $F_{rad} \text{ max.} = 105 \text{ kN}$, principle 1 would thus be satisfied.

In this example principle 2 is not relevant, because you are working without tailstock anyway.

Principle 3 would also be satisfied because the calcu-

lated cutting force of $F_c = 1226 \text{ N}$ is far below the limit of 4500 N.

In this example, principles 4 and 5 are again irrelevant because both principles must only be considered for radial drilling work.

Result of the sample calculation

All four limits are verified.

At full axial loading of the chuck with $F_{ax}=45 \text{ kN}$ a nominal 105 kN is applied radially on the workpiece. This satisfies the condition $F_{rad} \geq F_{rad\text{erf}}$.

Thus the machining can be executed.

It must be ensured that the chuck is in good condition relative to degree of contamination and lubrication.

A check of the radial clamping force with a suitable clamping force gauge must be executed in advance of the machining as a precautionary measure. The values determined in this process must be within the range shown in section 3 »Clamping force diagram « shown for RPM.

2.11 Environmental protection



NOTE!

Environmental hazard due to incorrect handling!

Incorrect handling of environmentally hazardous substances, particularly improper disposal, can cause significant environmental damage.

- Always comply with the instructions cited below
- If environmentally harmful substances should inadvertently get into the environment, initiate suitable measures immediately. If in doubt notify the responsible municipal authority about the damage.

The following environmentally harmful substances are used:

Lubricants

Lubricants like greases and oils can contain toxic substances. Ensure that they do not get into the environment.

The device must be disposed of by a specialized disposal company.

To achieve trouble-free operational performance of the clamping device only use HAINBUCH lubricants. See the appendix for reference addresses.

3 Technical data

3.1 General Information

Size	Variant	Clamping range [mm]	Release stroke [mm]	Clamping reserve [mm]	Weight clamping device [kg]	Weight spindle flange [kg]	Weight Clamping unit [kg]	Dimensions clamping unit [\varnothing x length in mm]	Connection spindle flange [\varnothing in mm]	Speed max. [1/min]	Axial clamping force F_{ax} max. [kN]	Radial clamping force F_{rad} max. [kN]
32	Combi pull-back	4-32	3	2,5	10	6	4	\varnothing 106 x 99,5	KK4, KK5 KK6, KK8 IP 100	8000	25	70 ¹⁶
	Combi deadlengt	4-32	3	2,5	10	5,5	4,5	\varnothing 162 x 100,5	KK4 KK5 KK6 IP 110 IP 130 IP 140	8000	25	70
	Modular	4-32	3	2,5	12,5	6	6,5	\varnothing 106 x 77	KK4 KK5 KK6 IP 115	8000	25	70
42	Combi pull-back	4-42	2,5	2	12	5,5	6,5	\varnothing 131 x 103,5	KK4, KK5, KK6 IP 100 IP 110 IP 115 IP 120 IP 140	7000	35	80 ¹⁶
	Combi deadlengt	4-42	2,5	2	14	4	10	\varnothing 162 x 101,5	KK4, KK5 KK6 IP 100, IP 108 IP 110, IP 120 IP 140, IP 170	7000	35	80
	Modular	4-42	2,5	2	11	5,5	5,5	\varnothing 131 x 83,5	KK4, KK5, KK6 IP 115 IP 120 IP 145 IP 170	7000	35	80

KK = short taper size, IP = inner fit dimensions, AP = outer fit dimensions

¹⁶ When using an end-stop, F_{rad} max is significantly lower!

SPANNTOP [nova] – Technical data

Size	Variant	Clamping range [mm]	Release stroke [mm]	Clamping reserve [mm]	Weight clamping device [kg]	Weight spindle flange [kg]	Weight Clamping unit [kg]	Dimensions clamping unit [ø x length in mm]	Connection spindle flange [ø in mm]	Speed max. [1/min]	Axial clamping force F _{ax} max. [kN]	Radial clamping force F _{rad} max. [kN]
52	Combi pull-back	3-52	2,5	2	11,5	5,5	6	ø 131 x 103,5	KK4, KK5 KK6, KK8 IP 120 IP 140	7000	40	94 ¹⁷
	Combi deadlengt	3-52	2,5	2	13	5	8	ø 162 x 101,5	KK4, KK5 KK6 IP 100 IP 120 IP 140 IP 170	7000	40	94
	Modular	3-52	2,5	2	11	5,5	5,5	ø 131 x 83,5	KK5 KK6 IP 115 IP 120 IP 140	7000	40	94
65	Combi pull-back	4-65	2,5	2	13	4,5	8,5	ø 148 x 111	KK4, KK5 KK6, KK8 IP 120 IP 140 IP 170 IP 185 IP 220	6000	45	105 ¹⁷
	Combi deadlengt	4-65	2,5	2	16	6	10	ø 165 x 116,5	KK4, KK5 KK6 AP 130 IP 110 IP 120 IP 140 IP 170	6000	45	105
	Modular	4-65	2,5	2	12	4,5	7,5	ø148 x 102,5	KK5, KK6 KK8 IP 120 IP 140 IP 170 IP 220	6000	45	105

KK = short taper size, IP = inner fit dimensions, AP = outer fit dimensions

¹⁷ When using an end-stop, F_{rad} max is significantly lower!

SPANNTOP [nova] – Technical data

Size	Variant	Clamping range [mm]	Release stroke [mm]	Clamping reserve [mm]	Weight clamping device [kg]	Weight spindle flange [kg]	Weight Clamping unit [kg]	Dimensions clamping unit [ø x length in mm]	Connection spindle flange [ø in mm]	Speed max. [1/min]	Axial clamping force F _{ax} max. [kN]	Radial clamping force F _{rad} max. [kN]
80	Combi pull-back	4-80	2,5	2	16	6	10	ø 165 x 111,5	KK4, KK5 KK6, KK8 KK11 IP 140 IP 170 IP 220	5500	50	115 ¹⁸
	Combi deadlengt	4-80	2,5	2	20	7	13	ø 179 x 120,5	KK5, KK6 KK8, KK11 IP 140 IP 170 IP 220	5500	50	115
	Modular	4-80	2,5	2	14	6	8	ø 165 x 102	KK6 KK8 KK11 IP 140 IP 170 IP 220	5500	50	115
100	Combi pull-back	15 - 100	5	3	33,5	12, 5	21	ø 219 x 128,5	KK4, KK5 KK6, KK8 KK11 IP 140 IP 170 IP 220	5000	65	150 ¹⁸
	Combi deadlengt	15 - 100	5	3	35	12	23	ø 220 x 145	KK5, KK6 KK8, KK11 IP 170 IP 220	5000	65	150
	Modular	15 - 100	5	3	14	6	8	ø 165 x 102	KK6 KK8 KK11 IP 140 IP 170 IP 220	5000	65	150

KK = short taper size, IP = inner fit dimensions, AP = outer fit dimensions

¹⁸ When using an end-stop, F_{rad} max is significantly lower!

SPANNTOP [nova] – Technical data

Size	Variant	Clamping range [mm]	Release stroke [mm]	Clamping reserve [mm]	Weight clamping device [kg]	Weight spindle flange [kg]	Weight Clamping unit [kg]	Dimensions clamping unit [\varnothing x length in mm]	Connection spindle flange [\varnothing in mm]	Speed max. [1/min]	Axial clamping force F_{ax} max. [kN]	Radial clamping force F_{rad} max. [kN]
120	Combi pull-back	16 - 120	3	3	42,5	15	27	\varnothing 239 x 139	KK6, KK8 KK11	3200	70	165 ¹⁹
	Combi deadlengt	16 - 120	3	3	51	17	34	\varnothing 154 x 148	KK6, KK8, KK11	3200	70	165
	Modular	16 - 120	3	3	38	15	23	\varnothing 154 x 148	KK8 KK11	3200	70	165
125	Combi pull-back	25 - 125	6	5	62	25	37	\varnothing 264 x 154	KK6, KK8 IP 220	3200	70	165 ¹⁹
	Combi deadlengt	25 - 125	6	5	63	29,5	41,5	\varnothing 274 x 158	KK6, KK8, IP 170 IP 220	3200	70	165
	Modular	25 - 125	6	5	52	19	33	\varnothing 264 x 144	KK8 KK11 IP 220	3200	70	165
140	Combi pull-back	27 - 140	3	3	54	18	36	\varnothing 260 x 152	KK6, KK8, KK11	3200	100	235 ¹⁹
160	Combi pull-back	27 - 160	3	3	64	21	43	\varnothing 290 x 152	KK6, KK8, KK11, IP 220	3200	100	235 ¹⁹

KK = short taper size, IP = inner fit dimensions, AP = outer fit dimensions

¹⁹ When using an end-stop, F_{rad} max is significantly lower!



WARNING!

Risk of injury!

Using false technical data can lead to serious personal injury and property damage.

- The technical data [label on the product, assembly drawing] must be observed and may not be modified by the operator!

3.2 Clamping force diagram

In the diagrams, the effects of friction and the clamping diameter are included.



NOTE!

The measured values for the radial clamping force F_{rad} may not leave the permitted area. Under optimal conditions, the values for F_{rad} are below the top, in bad conditions above the lower limit.

- If the measured clamping forces are outside the allowed range, the maintenance is mandatory to perform. After servicing, the clamping forces have to be re-examined.
- If the clamping force even after the maintenance is not in the permitted area please contact the manufacturer.

Example for size 42/52:

With an axial force F_{ax} of 25 kN the radial clamping force F_{rad} is, depending on the maintenance state of the clamping device, in the range between 22 kN and 66 kN; it must not be smaller than 22 kN.

3.2.1 Clamping force diagram – size 32




Fig. 5

3.2.2 Clamping force diagram – size 42/52

F_{rad} (kN)




Fig. 6

3.2.3 Clamping force diagram – size 65/80




Fig. 7

3.2.4 Clamping force diagram – size 100/125




Fig. 8

3.2.5 Clamping force diagram – size 140/160




Fig. 9

3.3 Operating conditions

Environment	Specification	Value	Unit
	Temperature range	15 - 65	°C

Mechanical actuating In each possible operating condition the maximum draw force and compressive force may not be exceeded!

3.4 Power specifications



NOTE!

Material damage if the power specifications do not agree!

If the power specifications of clamping device, machine adapter and machine do not agree, severe damage extending to total damage can occur.

- Only assemble clamping devices and adapters in machines with the same power specifications.

Information on maximum clamping force and drawtube force is provided on the clamping device and the adapter.

- If the power values become unreadable through the abrasive effect, please refer from the manual and/or get in contact to the manufacturer.

3.5 Type designation



Fig. 10

The type designation is on the product and includes the following information:

- 1 ID no. [marked with the # symbol]
- 2 Maximum speed [rpm]
- 3 Maximum clamping force [kN]

4 Structure and function

4.1 Overview and brief description of the SPANNTOP [nova] combi pull-back




Fig. 11

- | | |
|--------------------------------------|-----------------------------|
| 1. Clamping unit | 7. Spindle flange |
| 2. Cylindrical screw – coupling | 8. Clamping screw [3 pc.] |
| 3. Cylindrical screw – clamping unit | 9. Base end-stop [optional] |
| 4. Clamping head [optional] | 10. drawtube adapter |
| 5. Clamping screw – clamping head | 11. Positioning bore |
| 6. Coupling | |

Brief description

The SPANNTOP [nova] combi pull-back is a through-bore chuck for bar work and it can also be used as an end-stop chuck. When used as an end-stop chuck the base end-stop included in the scope of delivery is screwed into the chuck.

Due to the axial drawtube force that is produced by the drawtube component the workpiece is pulled firmly onto the fixed end-stop. The rigidity of the entire clamping device thus achieved makes it possible to also provide stable clamping for workpieces with an extremely short clamping length.

The spindle flange of the clamping device is mounted on the machine spindle. Then the clamping unit with the drawtube adapter, including threaded adapter [optional], is screwed onto the drawtube. After checking concentricity and face run the clamping head is inserted.

The workpieces that will be machined are now clamped into the clamping head.

4.2 Overview and brief description of the SPANNTOP [nova] combi deadlength




Fig. 12

- | | |
|--------------------------------------|----------------------------------|
| 1. Clamping unit | 8. Spindle flange |
| 2. Cylindrical screw - clamping unit | 9. Clamping screw [3 pc.] |
| 3. Lubricating nipple | 10. Base end-stop |
| 4. Clamping head [optional] | 11. Flange adapter |
| 5. Locating pin | 12. Cylindrical screw - coupling |
| 6. Guard bushing | 13. Positioning bore |
| 7. Centering disc | |

Brief description

The SPANNTOP [nova] combi deadlength is a through-bore chuck for bar work and it can also be used as an end-stop chuck. When used as an end-stop chuck the base end-stop included in the scope of delivery is screwed into the chuck.

Due to the axial fixed clamping head, shoulders that are short to clamp can be machined, and so can long workpieces that must be machined in sections and moved forward several times.

With the SPANNTOP [nova] combi deadlength clamping device you can grip without axial stress on the workpiece.

The spindle flange of the clamping device is mounted on the machine spindle. Then the clamping unit with the drawtube adapter, including threaded adapter [optional], is screwed onto the drawtube. After checking concentricity and face run the clamping head is inserted.

The workpieces that will be machined are now clamped into the clamping head.

4.3 Overview and brief description of the SPANNTOP [nova] modular




Fig. 13

- | | |
|-----------------------------------|----------------------|
| 1. Clamping element reception | 5. Spindle flange |
| 2. Clamping screw [3 pc.] | 6. SPANNTOP coupling |
| 3. Clamping head [optional] | 7. Positioning bore |
| 4. Clamping screw – clamping head | |

Brief description

The SPANNTOP [nova] modular is a through-bore chuck for bar work.

This means that additional rigidity of the entire clamping device is achieved.

The spindle flange of the clamping device is mounted on the machine spindle. Then the clamping unit with the drawtube adapter, including threaded adapter [optional], is screwed onto the drawtube. After checking concentricity and face run the clamping head is inserted.

The workpieces that will be machined are now clamped into the clamping head.

4.4 Optional Accessories

The accessories described here are not included in the scope of delivery.

Specially developed segmented clamping bushings match to the respective maximum RPM are available for each clamping device. Trouble-free and precise function of HAINBUCH clamping devices is only ensured when using original HAINBUCH segmented clamping bushings.

Lubricating grease and grease gun are required for cleaning and preservation of the clamping device. The lubricating grease is also specially matched for protection of the vulcanized segments of the segmented clamping bushings and increase their service life and elasticity by a significant factor.

4.4.1 Standard end-stop



Fig. 14

vario part [for precise, rigid clamping]

It functions like a gauge block set and can be adjusted with plates in steps of 1 mm. With a face run of < 0.02 mm at the workpiece touching part the vario part is perfect for machining of finished material.



Fig. 15

vario quick [for precise, rigid clamping]

This variant works with a precise trapezoidal thread, with that the clamping depth can be adjusted quickly. A half turn corresponds to 1 mm adjustment travel.

4.4.2 Workpiece end-stop




Fig. 16

The workpiece end-stop is manufactured with a end-stop dimension according to the customers request. In combination with the clamping head and the chuck it provides a functional unit.

4.4.3 Clamping head RD




Fig. 17

The clamping heads are used to accommodate the workpiece that will be machined. They consists of hard steel and rubber segments that are connected via a vulcanizing process.

Depending on the requirements of the workpiece there are clamping heads in different sizes and with different profiles and bores.

4.4.4 Changing fixture



Fig. 18

Manual changing fixture

The pins of the changing fixture are inserted in the matching holes in the clamping head. The changing fixture is tensioned via hand force. The clamping head is firmly clamped in the changing fixture and can be inserted into the mounted clamping device with the aid of the changing fixture.



Fig. 19

Pneumatic changing fixture

The pins of the changing fixture are inserted in the matching holes in the clamping head. The changing fixture is tensioned via compressed air. The clamping head is firmly clamped in the changing fixture and can be inserted into the mounted clamping device with the aid of the changing fixture.

4.4.5 Threaded adapter



Fig. 20

The threaded adapter acts as connector between the drawtube of the machine and the drawtube adapter of the clamping device and, depending on the machine type, can be designed in various forms.

4.4.6 Drawtube adapter




Fig. 21

The drawtube adapter acts as connector between the drawtube of the machine and the drawtube adapter of the clamping device and, depending on the machine type, can be designed in various forms.

4.4.7 Reducing coupling



Fig. 22

A reducing coupling is available for reduction of a SPANNTOP [nova] modular clamping device size 52 to size 42. With the reducing coupling, segmented clamping heads of size 42 may be inserted.

The reducing coupling can be ordered from HAINBUCH.

4.4.8 Assembly wrench



Fig. 23

An assembly wrench is required for assembly with the reducing coupling.

The assembly wrench can be ordered from HAINBUCH.

4.4.9 MANDO Adapt T211/T212




Fig. 24

- Adaption clamping device
MANDO Adapt T211/T212
 - The CENTREX quick change-over interface allows a μ -accurate adaption of the adaptation clamping device without adjusting the chuck.
 - Clamping range \varnothing 8-190 mm possible by several sizes of mandrel
 - MANDO Adapt T211: 20-120 mm
 - MANDO Adapt T212: 8-190 mm
 - Vibration damping by vulcanized segmented clamping bushings
 - Workpiece stabilization by axial traction to the workpiece end-stop
 - wide bridging area by vulcanized clamping elements

The MANDO Adapt can be ordered at HAINBUCH. For using the MANDO Adapt T211 RD an additional adaptation ring is required.

4.4.10 Jaw module



Fig. 25

The jaw module is an adaptation clamping element for using clamping jaws.

It can be used to extend the clamping range of the base clamping device. As a base clamping device for adapting the jaw module is used the SPANNTOP chuck.

Key advantages

- Minimal interference contour
- Dead-length clamping
- Rotating and stationary use
- Only external clamping possible
- Can be used as a pick-up chuck on sub spindles
- Milling between the jaws possible

4.4.11 Magnet module



Fig. 26

The magnet module is an adaptation clamping device for the use of ferromagnetic materials for grinding or turning. As a base clamping device for adapting the magnet module is used the SPANNTOP chuck.

Key advantages:

- Only for ferromagnetic materials
- Very good runout characteristics
- Deadlength clamping
- Rotating and stationary use
- Manually operated
- Very short chang-over time

4.4.12 Grease



Fig. 27

The grease for chuck and mandrel lubrication is supplied in a 1000g can. The order number for the grease is 2085/0003; it can be ordered from HAINBUCH.

5 Transporting, packaging and storing

5.1 Safety instructions for transporting

Unbalanced package



WARNING!

Danger of falling due to an unbalanced package

Packed goods can have an unbalanced package. If attached incorrectly the package can tip and cause life-threatening injuries.

- Note the markings on the packages.
- Attach the crane hook in such a manner that it is located above the center of gravity.
- Carefully lift and see if the load tilts. If necessary change the attachment.



Transport!

- For transport always use a suitable clamping means / crane.
- Make sure that a rolling / falling of the clamping device is not possible.

5.2 Symbols on the packaging



Fragile

Identifies packages with fragile or sensitive contents. Handle the packed goods with care; do not allow them to fall, and do not subject them to impact.



Protect from moisture

Keep packed goods dry and protected against moisture.

5.3 Transport inspection

Check delivery immediately upon receipt to ensure that delivery is complete and to identify any transport damage.

Proceed as follows if there is apparent external damage:

- Do not accept the delivery, or only accept it with reservation.
- Note the extend of transport damage on the transport documents or on the transport company's delivery ticket.
- Submit a complaint.



Report any defect as soon as it is detected. Claims for damage compensation can only be enforced during the applicable periods for giving notice of lack of conformity.

5.4 Unpacking and inner-company transportation



From about weight 15 kg there are threaded holes in the circumference of the clamping device. Lifting eye bolts can be screwed into these threaded holes.

For transporting with transport trolley the clamping device must be positioned in standing condition. Make sure that a non-slip pad has been laid.

To safely lift the clamping device out of the package it must be hooked into a crane depending on the weight.

All tools and accessories which are not in scope of delivery are marked as optional in the operating instructions.

Two people are required for this task.

Special tools required:

- Crane from weight more than 15 kg
- Lifting eye bolts



Fig. 28

1. Screw lifting eye bolt into the radial thread in the circumference of the clamping device.
2. Hook the load-handling equipment into the lifting eye bolt.
3. Use a crane to carefully lift the clamping device out of the transport packaging and put it down on a stable, level substrate.

5.5 Packaging

About the packaging

Individual packages are packed according to the expected transport conditions. Environmentally-friendly materials have been used exclusively for the packaging.

Packaging should protect the specific components from transport damage, corrosion, and other damage until installation. Therefore do not destroy the packaging, remove it just before installation.



The packed goods are sealed in foil airtight and packed in cartons. See the »Technical Data« section for the specific weight of the respective sizes.

Handling packaging materials

Dispose of packaging materials in accordance with the respectively valid statutory regulations and local guidelines.



NOTE!

Improper disposal causes environmental damage!

Packaging materials are valuable raw materials and in many cases they can be reused, or they can be effectively treated and recycled.

- Dispose of packaging materials in an environmentally responsible manner.
- Comply with locally applicable disposal guidelines. If necessary commission a specialized company to dispose of packaging.

5.6 Storing



Under certain circumstances instructions for storage and subsequent storage are affixed to the packages that extend beyond the requirements cited here.

Comply with these instructions accordingly.

Storage of packages Only store packages under the following conditions:

- Do not store outdoors.
- Store in a dry and dust-free location
- Do not expose to aggressive media
- Protect from direct sunlight
- Avoid mechanical vibration
- Storage temperature: 15 bis 35 °C
- Relative humidity: max. 60 %
- For storage periods longer than 3 months:
 - Check the general condition of all parts and the packaging at regular intervals.
 - Touch up or re-apply anti-corrosion agents as needed

Subsequent storage of the clamping device

Only re-store the clamping device under the following conditions:

- Thoroughly clean the clamping device prior to subsequent storage [see section »Cleaning«]
- Thoroughly oil and grease the clamping device. [see section »Cleaning«]
- Store the clamping device in airtight foil
- The clamping device must be stored securely in position. If this is not guaranteed, use a suitable container for the clamping device or equip the shelf with a circumferential securing edge.

6 Assembly



WARNING!

During the initial installation of the clamping device severe injuries may occur.

- The initial installation must be done only by qualified personnel.
- All screws remaining in the clamping must be tightened firmly.
- All tools and keys must be removed after installation.
- Always wear personal protective equipment!

6.1 Pre-consideration

- Screws are tightened according to the size of the screw and the general torque.
To avoid axis-parallel warpage under load and to get stiffness turn in the screws evenly.
- To avoid precision error clean the screw joint surfaces and also the mating surfaces, see »Maintenance«.
The ex works wetting of the plate surfaces and the clamping element is only corrosion protection. It's not functionally lubricated.
- The insertion of lubricant is provided only on the mechanical surfaces. Pay attention to the instructions for lubricants in the chapter »Maintenance«.
- Avoid too much lubricant on the bearing surface, as this can cause face runout.
- Seal rings [e.g. o-ring, quad-ring seal] and sealing surfaces must be lubricated.
Note the information in the chapter »Maintenance«.
- Note that the function surfaces [plate surface, mating surface, cone surface and seal surface] may not be damaged.



CAUTION!

Wear safety shoes during the assembly and maintenance work.

Make sure that the starting of the spindle is impossible.

6.2 Preparations

The total weight of the clamping device, consisting of spindle flange and clamping unit, depends on the size and can be as much as 65 kg.

The individual weight of the spindle flange can be as much as 26 kg, and the clamping unit can weigh up to 36 kg [see section »Technical data«].

Depending on the weight, to safely lift the clamping device out of the package and position it in the machine it must be hooked into a crane.



WARNING!

Danger of injury due to falling components!

When mounting components can fall and cause severe injury and material damage.

- Two people are always required for this task.
- Use a crane.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.

6.2.1 Preparing SPANNTOP nova combi deadlength and SPANNTOP nova combi pull-back clamping devices

Special tools required:

- Allen wrench
- Oil stone
- Crane and eye bolts from weight 15 kg



Fig. 29

1. Loosen all cylindrical screws [1] in the clamping device element reception [3] with an allen wrench [2] and remove them completely.



Fig. 30

2. Lift the clamping unit [1] off of the spindle flange.
3. Wipe off the mating surfaces on the spindle flange and clamping unit with a soft, lint-free cloth and remove all oil and grease residues.
4. Hone the mating surfaces on the spindle flange with an oil stone.

6.2.2 Preparing the SPANNTOP nova modular clamping device

Special tools required:

- Allen wrench
- Oil stone
- Crane and eye bolts from weight 15 kg



Fig. 31

1. Loosen all cylindrical screws [1] in the clamping device element reception [3] with an allen wrench [2] and remove them completely.



Fig. 32

2. Lift the clamping element reception [1] off of the spindle flange.



Fig. 33

3. Take the coupling [3] out of the spindle flange [1]. In this process ensure that the torsional safety pin [2] is kept safe and is not damaged.
4. Clean the mating surfaces on the spindle flange, drawtube adapter, coupling, and clamping unit with a soft, lint-free cloth and remove all oil and grease residues.
5. Hone the mating surfaces on the spindle flange with an oil stone.

6.3 Installation



WARNING!

Danger of injury due to unintentional start-up of a machine spindle!

Unexpected start up of a machine spindle can cause severe injury.

- Only run the machine in set-up mode or jog mode.
- Set the axial clamping force of the machine tool on the lowest setting.
- Always remove immediately all the tools and wrenches from the clamping device after use.
- Unscrew all eye bolts from the clamping device and remove them from the interior of the machine.
- Prior to switching on automatic mode close all protective doors or hoods that are present on the machine tool.



WARNING!

Risk of injury!

By operating the clamping device without changing parts [clamping head, workpiece end-stop] there is an increased risk of crushing injuries by the stroke of the moving components of the clamping device.

By uncontrolled discharge of the clamping process [e.g. by incorrect installation of the energy supply or faulty programming] there is an increased danger.



WARNING!

Risk of injury!

Bending in the working area of the machine can cause severe head injuries!



CAUTION!

Risk of injury!

Unexpected start up of the tool spindle can cause severe injury.

- Make sure that the system is pressure-free and that a restart of the machine can be excluded!



Risk of injury!

Contamination of the mechanism can influence/reduce the stroke, thus the clamping force is reduced and thus, the workpiece is not properly tightened and can be thrown out.

- Clean the product regularly [see chapter »Maintenance and service«].



CAUTION!

Risk of injury!

If the axial actuating force is too low clamped workpiece may be thrown out.

If the axial actuating force is too high severe damages of the components of the clamping device may occur the throwing out of the workpiece.

- Before operation set the operation pressure back to operation level.
- The radial clamping force should be checked and adjusted regularly!
- The dimension of the workpieces should be checked regularly [clamping- \emptyset]!



Transport!

- For transport always use a suitable clamping means / crane.
- Make sure that a rolling / falling of the clamping device is not possible.



WARNING!

Danger of injury due to vertical suspended spindle!

Bending into the machine work area when assembling overhead can cause severe head injuries.

- Secure components prior to overhead assembly.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.

6.3.1 Assembling the flange [optional]



NOTE!

Material damage due to wrong tightening torque of the cylindrical screws in the spindle flange!

The tightening torque of the cylindrical screws is prescribed by the spindle or machine manufacturer. Incorrect tightening torque of the cylindrical screws in the flange can cause significant material damage on the clamping device and on the machine.

- Only tighten the cylindrical screws of the spindle with the torque prescribed by the spindle or machine manufacturer.



Fig. 34

1. Put the machine in set up mode.
2. Wipe off the mating surfaces of the machine spindle with a soft, lint-free cloth and remove all oil and grease residues.
3. Lift the flange into the machine by hand or with the aid of a crane and place it on the machine spindle. Position the flange on the machine spindle with the aid of the bores.
4. Screw all cylindrical screws into the flange with an allen wrench and hand tighten in a cross pattern.
5. Now adjust the clamping device, see »Adjusting the concentricity of the spindle flange«.



NOTE!

Material damage is possible if the eye bolts are left in the spindle flange!

Eye bolts that are left in the clamping device can significantly damage or even destroy lathe, clamping device and workpiece.

- Always remove eye bolts immediately after mounting the clamping device in the lathe.

6.3.2 Adjusting the concentricity of the spindle flange



NOTE!

Material damage due to insufficient face run and concentricity!

Due to insufficient face run and concentricity workpieces can be damaged during processing.

- After each mounting check, and if necessary readjust, the face run and concentricity of the clamping device.

Auxiliary material required:

- Dial indicator
- Rubber mallet
- Torque wrench




Fig. 35

1. Wipe off the mating surfaces of the spindle flange with a soft, lint-free cloth and remove all oil and grease residues.
2. Place the magnetic base of the dial indicator on the inside of the machine.
3. Place the dial indicator for concentricity on the fit of the spindle flange.




Fig. 36

4. Adjust the spindle flange in such a manner that the dial indicator shows the value »0« [$\leq 0,005$ mm].




Fig. 37

5. Tighten all cylindrical screws with a torque wrench in a cross pattern [see section »Screw tightening torque«].



For exact adjustment, if necessary loosen the cylindrical screws a little, repeat the adjusting and retighten the cylindrical screws in a cross pattern.

6.3.3 Checking face run and concentricity




Fig. 38

1. Place the magnetic base of the dial indicator on the inside of the machine.
2. Place the dial indicator for concentricity on the inside edge of the spindle flange and check the concentricity [$\leq 0,005$ mm].




Fig. 39

3. Place the dial indicator for face run on the outer edge of the mating surface, check the face run [$\leq 0,005$ mm].
4. If face run and/or concentricity are larger than the maximum permissible value:
 - Disassemble the flange.
 - Clean all mating surfaces of spindle and spindle flange.
 - Re-assemble the flange.
 - Repeat the adjusting.

6.3.4 Installing the SPANNTOP [nova] combi deadlength or SPANNTOP [nova] combi pull-back clamping unit size 32-120

Special tools required:

- Allen wrench
- Crane and eye bolts from weight 15 kg



Fig. 40

1. Put the machine tool in set up mode.
2. Remove all tools from the interior of the machine.
3. Set the axial clamping force of the machine tool on the lowest setting.
4. Move the drawtube of the machine tool into the front stop position.
5. Screw the drawtube adapter [2] into the clamping unit [1].



WARNING!

Danger of injury due to vertical suspended spindle!

Bending into the machine work area when assembling overhead can cause severe head injuries.

- Secure components prior to overhead assembly.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.




Fig. 41

6. Vertically suspended assembly:
 - Place the assembly plate [illustration is symbolic] on the tool turret.
 - Use a crane to place the clamping unit with drawtube adapter on the assembly plate.
 - In jog mode, move the spindle slowly and carefully downward until it touches the clamping unit.
 - Screw the clamping unit clockwise into the machine spindle to the end-stop. If required, slowly and carefully move the machine spindle further downward. When screwing in the drawtube adapter, ensure that it does not tilt.




Fig. 42




Fig. 43

7. Horizontal or vertical standing assembly:

- Use a crane to lift the clamping unit with drawtube adapter into the machine and place it on the drawtube of the machine tool.
- Screw the drawtube adapter with the clamping unit onto the drawtube of the machine tool to the end. In this process ensure that the drawtube adapter does not tilt.



Do not tighten the drawtube adapter with clamping unit.

8. Turn back the clamping unit until the arrows of the balance marks are aligned.



The through-bore of the clamping element reception and the threaded bores of the spindle flange should now be aligned as well.



Depending on the machine type it may be necessary to comply with a given screw-in depth of the drawtube adapter.

- This dimension is pointed out in the assembly drawing of the clamping device.



WARNING!

Crushing danger due to machine movement!

It may not always be avoided that in the assembly of the clamping unit there is a gap between spindle flange and clamping unit.

Therefore the reasons are the position of the drawtube as well as the request to maximum usable work space.

Through this gap there is a higher risk of crushing that can lead to severe injuries.

- Never reach into the gap between spindle flange and clamping unit!




Fig. 44

9. Carefully move the drawtube of the machine tool back in jog mode, until the clamping unit is completely inserted in the spindle flange.
10. Screw all cylindrical screws 1] into the clamping unit with an allen wrench and hand tighten in a cross pattern.

6.3.5 Installing the SPANNTOP [nova] combi deadlength or SPANNTOP [nova] combi pull-back clamping unit size 125-160

Special tools required:

- Allen wrench
- Crane and eye bolts from weight 15 kg



Fig. 45

1. Put the machine tool in set up mode.
2. Remove all tools from the interior of the machine.
3. Set the axial clamping force of the machine tool on the lowest setting.
4. Move the drawtube of the machine tool into the front stop position.
5. Screw the drawtube adapter [2] into the clamping unit [1].



WARNING!

Danger of injury due to vertical suspended spindle!

Bending into the machine work area when assembling overhead can cause severe head injuries.

- Secure components prior to overhead assembly.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.




Fig. 46

6. Vertically suspended assembly:

- Place the assembly plate [illustration is symbolic] on the tool turret.
- Use a crane to place the clamping unit with drawtube adapter on the assembly plate.
- In jog mode, move the spindle slowly and carefully downward until it touches the clamping unit.




Fig. 47

7. Horizontal or vertical standing assembly:

- Use a crane to lift the clamping unit with drawtube adapter into the machine and place it on the drawtube of the machine tool.




Fig. 48

8. Insert wrench [if necessary through the assembly plate] into the clamping unit, so that the wrench engages in the grooves of the adapter.

9. Use the wrench to screw the adapter onto the drawtube of the machine, via the adapter thread, to the stop, without tightening. In this process ensure that the drawtube adapter does not tilt.



Do not tighten the drawtube adapter with clamping unit.




Fig. 49

10. Turn back the clamping unit until the arrows of the balance marks are aligned.



The through-bore of the clamping element reception and the threaded bores of the spindle flange should now be aligned as well.



Depending on the machine type it may be necessary to comply with a given screw-in depth of the draw tube adapter.

- This dimension is pointed out in the assembly drawing of the clamping device.



WARNING!

Crushing danger due to machine movement!

It may not always be avoided that in the assembly of the clamping unit there is a gap between spindle flange and clamping unit.

Therefore the reasons are the position of the drawtube as well as the request to maximum usable work space.

Through this gap there is a higher risk of crushing that can lead to severe injuries.

- Never reach into the gap between spindle flange and clamping unit!



Fig. 50

11. Carefully move the drawtube of the machine tool back in jog mode, until the clamping unit is completely inserted in the spindle flange.
12. Screw all cylindrical screws [1] into the clamping unit with an allen wrench and hand tighten in a cross pattern.

6.3.6 Assembly of the SPANNTOP [nova] modular

Two people are required for this task.

Special tools required:

- Allen wrench
 - Crane and eye bolts from weight 15 kg
1. Put the machine tool in set up mode.
 2. Remove all tools from the interior of the machine.



Fig. 51




Fig. 52




Fig. 53




Fig. 54




Fig. 55

3. Reduce the axial clamping force of the machine to lowest level.
4. Move the drawtube of the machine tool into the front stop position.
5. Screw the drawtube adapter [1] into the coupling [2].
6. Lift the coupling with drawtube adapter into the machine and place it on the drawtube of the machine tool.
7. Screw the drawtube adapter with coupling onto the drawtube of the machine tool to the end. In this process ensure that the drawtube adapter does not tilt.



Do not tighten the drawtube adapter with clamping unit.

8. Turn the coupling back until the coupling groove [2] is aligned flush with the [1] groove of the spindle flange.
9. Insert the torsional safety element [1] vertically into the coupling groove and slide it into the groove of the spindle flange [1].



Coupling and spindle flange are now fixed in place. To prevent the torsional safety element from tilting, carefully pull the coupling again approximately 1 cm horizontally out of the spindle flange to the front.

In this process ensure that the drawtube adapter does not tilt.

10. Place the clamping unit [2] on the coupling and slide it into the spindle flange [1].




Fig. 56

11. Turn back the clamping unit until the arrows of the balance marks are aligned.



The through-bore of the clamping element reception and the threaded bores of the spindle flange should now be aligned as well.



Depending on the machine type it may be necessary to comply with a given screw-in depth of the drawtube adapter.

- This dimension is pointed out in the assembly drawing of the clamping device.



WARNING!

Crushing danger due to machine movement!

It may not always be avoided that in the assembly of the clamping unit there is a gap between spindle flange and clamping unit.

Therefore the reasons are the position of the drawtube as well as the request to maximum usable work space.

Through this gap there is a higher risk of crushing that can lead to severe injuries.

- Never reach into the gap between spindle flange and clamping unit!



Fig. 57

12. Carefully move the drawtube of the machine tool back in jog mode, until the clamping unit is completely inserted in the spindle flange.

13. Screw all cylindrical screws [1] into the clamping unit with an allen wrench and hand tighten in a cross pattern.

6.3.7 Checking and adjusting the face run and concentricity of the clamping unit



NOTE!

Material damage due to insufficient face run and concentricity!

Due to insufficient face run and concentricity workpieces can be damaged during processing.

- After each mounting check, and if necessary readjust, the face run and concentricity of the clamping device.

Special tools required:

- Dial indicator
- Plastic tip hammer
- Torque wrench




Fig. 58

Checking face run

1. Place the magnetic base of the dial indicator on the inside of the machine.
2. Place the dial indicator for face run on the front face of the spindle flange, check the face run [$\leq 0,005$ mm].
3. Adjust the clamping unit [by using a plastic hammer] in such a manner that the dial indicator shows the value »0« [$\leq 0,005$ mm].




Fig. 59

Checking concentricity

4. Place the magnetic base of the dial indicator on the inside of the machine.
5. Place the dial indicator for concentricity on the clamping cone.
6. Adjust the clamping unit [by using a plastic hammer] in such a manner that the dial indicator shows the value »0« [$\leq 0,005$ mm].



For exact adjustment, if necessary loosen the cylindrical screws several turns and retighten in a cross pattern.




Fig. 60

7. Tighten the cylindrical screws with a torque wrench in a cross pattern [see section »Screw tightening torque«].



For exact adjustment, if necessary loosen the cylindrical screws several turns and retighten in a cross pattern.

8. Wipe off the taper reception in the clamping unit with a soft, lint-free cloth and remove all oil and grease residues.

6.3.8 Assembly of the clamping device to an interface

The clamping device can be provided with an interface:

1. centroteX / centroteX-V
2. capteX B / capteX D

The assembly of the clamping unit to one of the named interfaces is described in the corresponding manual of the interface.

6.3.9 SPANNTOP [nova] modular – reduction of the size

The SPANNTOP [nova], size 52 can be reduced to size 42.

Special tools required:

- Assembly wrench



Fig. 61

The following steps are required for reduction of the size:

1. If necessary remove the reducing sleeve installed by the customer.
2. Insert the assembly wrench into the reducing coupling. To do this, guide the pins of the assembly wrench into the grooves of the reducing coupling.
3. Now use the assembly wrench to screw the reducing coupling into the clamping device and firmly tighten it.

4. Remove the assembly wrench from the clamping device.

The reducing coupling is installed.

6.3.10 Installing the base end-stop



If the SPANNTOP [nova] combi deadlength or SPANNTOP [nova] combi pull-back clamping devices will be used as end-stop chuck the base end-stop must be mounted.

The SPANNTOP [nova] modular clamping device can only be used as a through-bore chuck and thus has no base end-stop.

Special tools required:

- Allen wrench
- Mounting bolt or suitable cylindrical screw

1. Take the clamping head out of the taper.
2. Unscrew the clamping screws [see section »Disassembling the base end-stop«].
3. Screw the mounting bolt clockwise into the threaded bore in the center of the base end-stop.



Fig. 62



Screw the mounting bolt into the base end-stop so that the polished side of the base end-stop is pointing up.



Fig. 63

4. Use the mounting bolt to insert the base end-stop into the clamping device in such a manner that the lateral fixing pin of the base end-stop is aligned flush with the fixing groove in the centering disk.



NOTE!

Material damage is possible if the clamping screws are tightened too forcefully!

Tightening the clamping screws too forcefully can damage or destroy them. The base end-stop can no longer be clamped in.

- Tighten the clamping screws by hand.
- Do not screw in beyond the resistance.



Fig. 64




Fig. 65

5. Tighten all clamping screws of the base end-stop in the spindle flange clockwise with an allen wrench. The base end-stop is now secured.




Fig. 66

6. Unscrew the mounting bolt counterclockwise and remove it completely.

6.3.11 Assemble the clamping head



For changing in the clamping head move the coupling of the clamping device to front end position.

Depending on the model of the clamping head the handling of the changing fixture is easier or more difficult.




Fig. 67



WARNING!

Danger of violent pressure to hands and fingers!

- Before working at the installed clamping device make sure that starting of the machine is impossible.
- Only run the machine in set-up mode or jog mode.
- During operation never reach into the coupling or slot area of the clamping head nor in the changing fixture.

6.3.12 Assembly of the workpiece end-stop

Special tools required:

- Allen wrench



Fig. 68

1. Put the workpiece end-stop through the assembled clamping head into the clamping device.



NOTE!

Material damage is possible if the mounting screws are tightened too forcefully!

Tightening the mounting screws too forcefully can damage or destroy them.

- Tighten the mounting screws by hand.
- Do not screw in beyond the resistance.

2. Screw in and firmly tighten mounting screws.



WARNING!

Risk of injury!

Tools and gages that are thrown out of the machine can cause injury.

- Remove all tools and gages from the working area of the machine before the machine is started up.



CAUTION

Damage of the clamping device!

If the axial actuating force is too low the clamped workpieces may be thrown out.

- Before operation set the axial clamping force back to operation level.
- The operating axial clamping force should be checked and adjusted regularly!



WARNING!

Risk of injury!

Escaping [sprayed out] hydraulic oil from adjacent machine components can cause serious personal injuries.

- Make sure that all O-rings / seals for the hydraulic and/or pneumatic connections are available and undamaged!

6.4 Workpiece




Fig. 69



WARNING!

Risk of injury due to thrown out parts!

During clamping of the workpiece and the processing parts can be thrown and cause severe injuries and property damage.

- Check the clamping diameter of the workpiece.
- Only clamp workpieces that meet the dimensional requirements, in this regard pay attention to the maximum utilization of the clamping reserve/reserve stroke, see chapter 2.5 »Faulty workpiece clamping«.
- Only clamp workpieces with a minimum clamping depth » L_{sp} «, **see chapter »Implementation limits«**.
As in this case only the area of the taper without front nose extension applies.
- To clamp extremely long workpieces, in addition use a tailstock/steady rest for support.



NOTE!

Material damage due to inappropriate workpieces!

- Only clamp workpieces that meet the dimensional requirements.
- For the dimensional requirements see chapter 3 »Technical data«.



CAUTION

Risk of injury!

When placing the workpiece:

- Make sure that the hands / fingers may not be clamped when inserting the workpiece!

6.5 Inspections



NOTE!

Material damage due to damaged clamping devices!

A damaged, incomplete, or unbalanced clamping device can significantly damage or even destroy the machine tool and the workpiece.

- Only install undamaged, complete, and precisely balanced clamping devices.
- If in doubt contact the manufacturer.

Ensure the following points prior to each installation and start-up of the clamping device:

- All cylindrical screws of the clamping device must be present and tightened with the proper tightening torque.
- The balance screws [if provided] of the clamping device must all be present and undamaged.
- All rubber segments must be intact; this means that they are neither torn, nor are they porous at any point.
- All edges and bearing surfaces are intact; this means that they are neither broken nor do they show any signs of wear.
- The set speed of the machine tool should not exceed the maximum permissible speed of the clamping device.

- The maximum actuating force specified on the perimeter of the clamping device must not be exceeded.
- The axial actuating force of the machine must be sufficiently high.
- All mounting tools must be removed from the interior of the machine.
- Clamping device and workpiece must be compatible – check the clamping diameter regularly.
- The workpiece must be clamped into the clamping device with sufficient workpiece tension.
- Do a a measurement of clamping force.

6.6 Control of the stroke position



WARNING!

Crushing danger from moving parts!

Crushing danger from moving parts during controlling the stroke position!

Gaps, caused while controlling the stroke position, can cause severe injury.

- Only do the controlling of the stroke position with assembled changing parts.
- Only run the machine in set-up mode or jog mode.
- Do not reach into moving parts or handle moving parts during operation.
- Note the gap dimensions of moving parts.
- Wearing of gloves / [PSA] is required!

6.7 Activities after production is concluded

1. Move the clamping device into unclamped position.
2. Switch off the machine tool and safeguard it from being switched on again.
3. Open the protective door or hood.
4. Clean the clamping device and a possibly mounted add on clamping device and adapter of chips and production residues using a soft, lint-free cloth and oil them lightly.
5. Close the protective door or hood.

7 Disassembly

If there is break in production that lasts longer than 3 days, the clamping device must be disassembled and properly stored in accordance with the manufacturer's specifications [see section »Transport, packaging, storage«].

Prior to disassembling:

- Put the machine in set up mode.
- Remove fuels and auxiliary materials, as well as residual processing materials and dispose of these items in an environmentally-responsible manner.

7.1 Safety

Safeguarding against restart



DANGER!

Life-threatening danger if restarted without authorization

When disassembling there is danger of the energy supply being switched on inadvertently. This poses a life-threatening hazard for persons in the danger zone.

- Prior to starting the tasks switch off all energy supplies and safeguard them from being switched on again.



WARNING!

Danger of injury due to falling components!

When mounting components can fall and cause severe injury and material damage.

- Two people are always required for this task.
- Use a crane.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.



WARNING!

Danger of injury due to vertical suspended spindle!

Bending into the machine work area when assembling overhead can cause severe head injuries.

- Secure components prior to overhead assembly.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.



Transport!

- For transport always use a suitable clamping means / crane.
- Make sure that a rolling / falling of the clamping device is not possible.

7.2 Disassembly of the workpiece end-stop

Special tools required:

- Allen wrench



Fig. 70

1. Loosen and remove the mounting screws.
2. Remove the workpiece end-stop out of the clamping device through the assembled clamping head

7.3 Disassemble the clamping head



For changing in the clamping head move the coupling of the clamping device to front end position.

Depending on the model of the clamping head the handling of the changing fixture is easier or more difficult.




Fig. 71



WARNING!

Danger of violent pressure to hands and fingers!

- Before working at the installed clamping device make sure that starting of the machine is impossible.
- Only run the machine in set-up mode or jog mode.
- During operation never reach into the coupling or slot area of the clamping head nor in the changing fixture.

7.4 Disassembling the base end-stop

Special tools required:

- Allen wrench
- Mounting bolt or suitable cylindrical screw




Fig. 72




Fig. 73




Fig. 74

1. Take the clamping head out of the taper of the clamping element reception.
2. Insert the mounting bolt [1] and screw it clockwise into the threaded bore in the center of the base end-stop.



NOTE!

Material damage if the clamping screws are loosened incorrectly!

Tightening the clamping screws too forcefully can damage or destroy them. The base end-stop can no longer be clamped in.

- Loosen the clamping screws by hand.
- Do not unscrew beyond the resistance.

3. Carefully loosen all clamping screws [1] with an allen wrench counterclockwise until resistance is tangible.
The base end-stop is now loosened.
4. Carefully pull out the base end-stop [1] straight from the front.

7.5 Disassembly of the clamping device from an interface

The clamping device can be provided with an interface:

1. centroteX / centroteX-V
2. capteX B / capteX D

The disassembly of the clamping device from one of the named interfaces is described in the corresponding manual of the interface.

7.6 Disassembling the clamping unit SPANNTOP [nova] combi deadlength and SPANNTOP [nova] combi pull-back size 32-120

- From weight 15 kg the task requires two people, or use a crane.
- Special tools required:
 - Use load-handling equipment from weight 15 kg
 - Allen wrench
- 1. Put the machine tool in set up mode.
- 2. Disassemble the base end-stop [see section »Disassembling the base end-stop«].
- 3. From weight 15 kg mount the eye bolts [see section »Unpacking and inner-company transport«].



WARNING!

Danger of injury due to vertical suspended spindle!

Bending into the machine work area when assembling overhead can cause severe head injuries.

- Secure components prior to overhead assembly.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.




Fig. 75

- 4. Vertically suspended disassembly:
 - Place the assembly plate [illustration is symbolic] on the tool turret.
 - In jog mode, move the spindle slowly and carefully downward until the clamping unit touches the assembly plate.
 - Loosen and remove the cylindrical screws using an Allen wrench.
 - Turn the clamping unit counterclockwise so that it comes out of the machine spindle. If required, slowly and carefully move the machine spindle upward.
 - When the clamping unit is completely disassembled, move the machine spindle completely upward.
 - Use a crane to take the clamping unit with draw-tube adapter off of the assembly plate.
 - Remove the assembly plate from the tool turret.




Fig. 76




Fig. 77



Fig. 78

5. Horizontal or vertical standing disassembly:

- Loosen and remove the cylindrical screws by using an allen wrench.

- Move the drawtube of the machine tool into the front stop position.
- Unscrew the clamping unit together with the drawtube adapter from the drawtube of the machine. Make sure that the drawtube adapter does not tilt.

6. Lift the clamping unit with the drawtube adapter [if necessary by using a crane] out of the machine and place it safely.

7.7 Disassembling the clamping unit SPANNTOP [nova] combi deadlength and SPANNTOP [nova] combi pull-back size 125-160

Two people are required for this task.

Special tools required:

- Allen wrench
 - Crane and eye bolts
1. Put the machine tool in set up mode.
 2. Disassemble the base end-stop [see section »Disassembling the base end-stop«].
 3. From weight 15 kg mount the eye bolts [see section »Unpacking and inner-company transport«].



WARNING!

Danger of injury due to vertical suspended spindle!

Bending into the machine work area when assembling overhead can cause severe head injuries.

- Secure components prior to overhead assembly.
- For assembly on a vertically suspended spindle always use a suitable mounting aid.



Fig. 79

4. Loosen all cylindrical screws [1] with an allen wrench and unscrew them from the clamping unit.




Fig. 80

5. Vertically suspended disassembly:
 - Place the assembly plate [illustration is symbolic] on the tool turret.
 - In jog mode, move the spindle slowly and carefully downward until it touches the clamping unit.




Fig. 81

6. Insert wrench [if necessary through the assembly plate] into the clamping unit, so that the wrench engages in the grooves of the adapter.
7. Use the wrench to unscrew the adapter from the drawtube of the machine, via the adapter thread. In this process ensure that the drawtube adapter does not tilt.




Fig. 82

8. Vertically suspended disassembly:

- Move the machine spindle completely upward.
- Use a crane to take the clamping unit off of the assembly plate and set it down at a safe place.
- Remove the assembly plate from the tool turret.




Fig. 83

9. Horizontal or vertical standing disassembly:

- Use a crane to take the clamping unit off of the assembly plate and set it down at a safe place.

The clamping unit is disassembled.

7.8 Disassembling the SPANNTOP nova modular clamping unit

From weight 15 kg the task requires two people, or use a crane.

Special tools required:

- Use load-handling equipment from weight 15 kg
- Allen wrench




Fig. 84

1. Put the machine tool in set up mode.
2. From weight 15 kg mount the eye bolts [see section »Unpacking and inner-company transport«].
3. Loosen all cylindrical screws [1] with an allen wrench and unscrew them from the clamping unit.




Fig. 85

4. Move the drawtube of the machine tool into the front stop position.
5. Pull the clamping element reception [2] off of the spindle flange [1] and lift it out of the machine.




Fig. 86

6. Remove the torsional safety element [1].
7. Unscrew the coupling with drawtube adapter [2]. In this process ensure that the torsional safety element is kept safe and is not damaged.

7.9 Disassembling the spindle flange

From weight 15 kg the task requires two people, or use a crane.

Special tools required:

- Torque wrench
- Allen wrench
- Crane and eye bolts from weight 15 kg




Fig. 87




Fig. 88

1. If necessary mount the eye bolts [see section »Unpacking and inner-company transport«].
2. Loosen all cylindrical screws [1] with a torque wrench [2] in a cross pattern.
3. Remove all cylindrical screws from the spindle flange.
4. Take the spindle flange [2] down from the machine spindle [1] by hand or with the aid of load-handling equipment and lift it out of the machine tool.
5. Wipe off the mating surfaces of the machine spindle with a soft, lint-free cloth and remove all oil and grease residues.
6. Remove all tools from the interior of the machine.

7.10 Subsequent storage of the clamping device

The clamping device must be cleaned and treated with corrosion protection for subsequent storage [see section »Cleaning«].



NOTE!

The storage conditions are specified in the section »Transport, packaging and storage«.

7.11 Disposal

If a return or disposal agreement has not been concluded, then recycle disassembled components.



CAUTION!

Risk of injury due to leaking fluids!

Hydraulically or pneumatically operated clamping devices may contain residues of liquids. Uncontrolled leakage of fluids can lead to severe injuries.

- Open the pressure relief screw and drain remaining liquid.
- Discard the liquid.



NOTE!

Improper disposal causes environmental damage!

Lubricants and other auxiliary materials are subject to treatment as special waste, and should only be disposed of by approved specialist companies!



NOTE!

Composite materials!

For disposal clamping devices which include composite materials [mineral cast, CFK] must be returned at HAINBUCH!

Local municipal authorities or specialized disposal companies provide information on environmentally-responsible disposal.

8 Maintenance

Environmental protection

Comply with the following instructions for environmental protection when performing maintenance work:

- At all lubricating points where lubricant is applied by hand, remove escaping, used, or excess grease, and dispose of it in accordance with applicable local regulations.
- Collect used oil in suitable containers and dispose of it in accordance with applicable local regulations.

8.1 General

Cleanliness of the appropriate end-stop as well as the guidance diameters are conditions for reaching the concentricity and perpendicularity tolerances. Clean these surfaces with an appropriate cleaner.



WARNING!

Risk of injury!

Always comply with the safety data sheets and guidelines provided by the manufacturer.



CAUTION

Danger of injury due to loss of clamping force!

Fouling of the clamping device can cause the clamping device to lose considerable clamping force.

- Always comply with the maintenance and cleaning intervals specified in this manual.
- In conjunction with the maintenance intervals, regularly check the maintenance status of the clamping device through clamping force measurements.



Risk of injury!

Slipping while the lubricating with a grease gun can lead to severe cuts!

8.2 Cleaning



WARNING!

Risk of injury due to cleaning with compressed air!

By cleaning the mechanic with compressed air, fine chips may cause injuries at the eyes and risk of cutting.

- Never clean the clamping device with compressed air!
- Always wear personal protective equipment!



Fig. 89

Auxiliary material required:

- Ester-free, non-polar cleaning agent
- Soft, lint-free cloth

1. Disassemble the clamping device [see section »Disassembling the clamping unit«].
2. Clean all the components listed below with cleaning agent and a cloth; remove all oil and grease residues:

- Spindle flange
- Clamping unit
- Taper reception and coupling area
- Drawtube adapter
- Threaded adapter [optional]
- Cylindrical screws

3. For the SPANNTOP [nova] modular, in addition also clean the coupling with torsional safety element with cleaning agent and cloth; remove all oil and grease residues.
To do this take the torsional safety element out of the coupling groove.

8.3 Preservation




Fig. 90

■ Special tools required:

- Universal grease 2085/0003
- Grease gun
- Oil stone
- Soft, lint-free cloth

1. Disassembling the clamping device [see section » Disassembling the clamping unit«].
2. Hone all the bearing surfaces of the clamping device with an oil stone.
3. For the SPANNTOP [nova] modular, in addition hone all bearing surfaces of the coupling [1] with an oil stone and apply a thin layer of grease to the torsional safety element. Remove excess grease with a cloth.
4. Lightly grease all cylindrical screws. Remove excess grease with a cloth.
5. Remount the clamping devices. To do this, for the SPANNTOP [nova] combi deadlength and combi pull-back variants, re-insert the clamping unit in the spindle flange.
6. For the SPANNTOP [nova] modular variant first, insert the coupling with the torsional safety element in the spindle flange and then mount the clamping unit.
7. Screw all cylindrical screws into the clamping device again and tighten them hand tight.

! For subsequent storage tightening the cylindrical screws hand tight suffices. This facilitates re-commissioning and protects the cylindrical screws.



Fig. 91

8. Use the lubricating nipples to grease the SPANNTOP [nova] combi deadlength clamping unit with a grease gun and universal grease.
9. Lightly grease all interior and outer surfaces of the clamping device. Remove excess grease with a cloth.
10. Pack the clamping device airtight in foil. Place it on a level, impact-free storage location and safeguard it from falling.

8.4 Use of lubricant

With the usage of lubricant you may only use grease that corresponds to the requirements concerning bond, pressure-stability and solubility in lubricating coolant. In addition no dirt particles may be in the grease; they cause run errors if they come in in-between two mating surfaces.

We recommend for this the following lubricant:

HAINBUCH grease

See optional Accessories

Alternatives:

Lubricant	Manufacturer	Product
Universal grease	MicroGleit	GP 355
	Klüber	QNB 50
	Zeller & Gmelin	DIVINOL SD24440
	Bremer & Leguill	RIVOLTA W.A.P.
Special grease	Klüber	MICROLUBE GL 261

8.5 Maintenance schedule

Maintenance tasks are described in the sections above that are required for optimal and trouble-free operation. If increased wear is detected during regular inspections, then reduce the required maintenance intervals according to the actual indications of wear. Contact the manufacturer, [see the service address on the back] if you have questions concerning maintenance tasks and intervals.

Interval	Maintenance task
Daily	Visual inspection and complete cleaning in case of heavy contamination [see section »Cleaning«]
	Check the end position sensing of the machine regularly.
	Clamping force measurement.
Weekly	Clean the clamping unit [see section »Cleaning«]
	Clean the taper reception and coupling area [see section »Cleaning«]
	Grease the clamping unit [see section »Preservation«]
Every 6 months	Completely disassemble and clean the clamping unit [see section »Cleaning«]





For proper operation of the coolant feed a pre-filtering with duplex filter [mesh size 100 µm, PI 3754] is necessary. The duplex filter is mounted on the coolant cleaning system.

8.6 Bolt torque

Metric ISO thread

The guide values for bolt tightening torque for achieving the highest permissible pre-tension for metric ISO thread are specified in Nm in the table.

■ Total friction coefficient $\mu_{\text{tot}} = 0,12$

Diameter	 [mm]	 [mm]	Torque for screw quality 10.9 [Nm]
M 4	7	3	4
M 5	8	4	7
M 6	10	5	12
M 8	13	6	25
M 10	17	8	50
M 12	19	10	100
M 16	24	14	220
M 20	30	17	400
M 24	36	19	600

The table shows the prescribed values.

Knowledge of the applicable guidelines and configuration criteria are the prerequisites.

9 Trouble shooting

Possible fault causes and the tasks to correct these faults are described in the following section.

If faults occur more frequently, the maintenance intervals must be shortened to correspond to the actual system load.

Contact the manufacturer if there are faults that cannot be corrected by following the instructions below; see the service address on the back of this operating instruction.

9.1 Safety

Trouble shooting

The following always applies:

1. For faults that pose a direct danger for personnel and or property immediately execute the emergency-stop function of the machine.
2. Determine the cause of the fault.
3. If correction of the fault requires work in the danger zone, put the machine in set-up mode.
4. Immediately inform the responsible parties at the installation site of the fault.
5. Depending on the type of fault, either have authorized specialized personnel correct the fault, or correct it yourself.



The trouble shooting table provided below lists personnel who are authorized to correct the fault.

6. If there is a fault that was not caused by the clamping device the cause of the fault may be in the machine area. See the operating manual for the machine in this regard.

9.2 Trouble shooting table

Fault	Possible cause	Fault correction	Corrected by
Clamping head cannot be replaced	The change gap between the clamping head coupling and workpiece end-stop is insufficient.	Rework the workpiece end-stop	Specialist
Clamping device does not open or the release stroke is insufficient.	Fouling between the draw mechanism and the clamping unit	Remove the clamping head, move the draw tube back and clean the coupling area [see section »Disassembling the clamping head«].	Specialist
	Dimensional deviation of the draw tube adapter	Check the dimensions of the draw tube adapter and correct them if necessary.	Specialist
Clamping force is too low	Workpiece is under-dimensioned	Replace with a suitable clamping head	Specialist
	Insufficient hydraulic pressure on the clamping cylinder	Check the machine-side hydraulic aggregate	Hydraulic specialist
	Defective clamping cylinder or blocked draw tube	Contact the machine manufacturer	Machine manufacturer
	Compression springs fatigued [at permanent tension]	Replace compression springs	Specialist
Eccentric dimensional deviation on the workpiece	Concentricity error of the clamping unit	Check the concentricity on the clamping taper and correct it if necessary [see section »Checking and adjusting the face run and concentricity of the clamping unit«].	Specialist
Dimensional deviation on the workpiece	Contaminated coupling area	Clean the coupling area of the clamping unit [see section »Cleaning«].	Specialist
	Contaminated clamping taper	Remove the clamping head and clean the clamping taper [see section »Cleaning«].	Specialist

Fault	Possible cause	Fault correction	Corrected by
Formal defect on the workpiece	Elastic deformation of feedstock that is subject to formal defects. After machining, the workpiece returns to its original form.	Use feedstock with fewer formal defects. Use a clamping head with several sharp teeth in the clamping surface.	Specialist
Marks on the clamping surface	Point or linear workpiece clamping	Replace with a clamping head that has a smoother clamping surface	Specialist
	Wrong clamping head type	Replace the clamping head	Specialist
	Excessive dimensional difference between the workpiece diameter and the clamping bore	Replace with a clamping head that has a suitable clamping bore	Specialist

9.3 Start-up after corrected fault

After correcting the fault execute the following steps to start up again:

1. Reset the emergency-stop device
2. Acknowledge the fault on the machine tool controller
3. Ensure that no one is in the danger zone
4. Start the machine tool

10 Appendix

10.1 Service Hotline

Order Hotline

Quickly ordered and delivered. A call is all it takes:
+49 7144. 907-333

Schedule Hotline

Current status of your order? Just call:
+49 7144. 907-222

24h emergency call

Has there been a crash or other technical emergency?

Our experts are at your service around the clock:
+49 7144. 907-444

10.2 Representatives

The sales partners and service employees listed at www.hainbuch.com are available for further consultation or support.

Index

A

Accessories.....

Assembly wrench.....	57
Changing fixture, manual.....	56
Changing fixture, pneumatic.....	56
Clamping head RD.....	56
Drawtube adapter.....	57
Grease.....	59
Jaw module.....	58
Magnet module.....	59
optional.....	55
Reducing coupling.....	57
Standard end-stop.....	55
Threaded adapter.....	57
Workpiece end-stop.....	56

Adjusting.....

Spindle flange.....	70
---------------------	----

Assembly.....

Clamping device to interface.....	80
Clamping head.....	82
Flange.....	69
SPANNTOP [nova] combi deadlength - size 125-160.....	74
SPANNTOP [nova] combi deadlength - size 32-120.....	72
SPANNTOP [nova] combi pull-back - size 125-160.....	74
SPANNTOP [nova] combi pull-back - size 32-120.....	72
SPANNTOP nova modular.....	76
Workpiece.....	84
Workpiece end-stop.....	83

B

Bolt torque.....

.....	103
-------	-----

Brief description.....

SPANNTOP nova combi deadlength	52
SPANNTOP nova combi pull-back.....	50
SPANNTOP nova modular.....	54

C

Carbon / CFK.....

.....	9
-------	---

Cleaning.....

.....	99
-------	----

Control of the stroke position.....

.....	86
-------	----

D

dangers.....

.....	14
-------	----

Description of variants.....

.....	5
-------	---

Disassembly.....

Clamping device from interface.....	90
Clamping head.....	89

SPANNTOP [nova] combi deadlength size 125-160.....

.....	92
-------	----

SPANNTOP [nova] combi deadlength size 32-120.....

.....	91
-------	----

SPANNTOP [nova] combi pull-back size 125-160.....

.....	92
-------	----

SPANNTOP [nova] combi pull-back size 32-120.....

.....	91
-------	----

SPANNTOP nova modular.....

.....	95
-------	----

Spindle flange.....

.....	96
-------	----

Disposal.....

.....	97
-------	----

E

Environmental protection.....

.....	38
-------	----

I

Implementation limits.....

.....	19
-------	----

Inspections.....

.....	85
-------	----

Intended use.....

.....	12
-------	----

L

loads.....

.....	15
-------	----

M

Maintenance schedule.....

.....	102
-------	-----

MANDO Adapt T211/T212.....

.....	58
-------	----

O

Operating conditions.....

.....	49
-------	----

Overview.....

SPANNTOP nova combi deadlength	52
---	----

SPANNTOP nova combi pull-back.....	50
------------------------------------	----

SPANNTOP nova modular.....	54
----------------------------	----

P

Packaging.....

.....	62
-------	----

Personal protective equipment.....

Hard hat.....	14
Protective gloves.....	14
Protective goggles.....	14
Protective work clothing.....	13
Safety footwear.....	13

Personnel requirements.....

.....	11
-------	----

Power specifications.....

.....	49
-------	----

Preparation.....

SPANNTOP nova combi deadlength	65
SPANNTOP nova combi pull-back.....	65
SPANNTOP nova modular.....	66

Preservation.....

.....	100
-------	-----

PSA [Personal protective equipment].....

.....	13
-------	----

S

Schutzausrüstung.....

.....	
-------	--

Haarnetz.....	14	Transport, inner company.....	61
Scope of delivery.....	8	Trouble shooting.....	104
Spare parts.....	9	Trouble shooting table.....	105
Storing.....	63	Type designation.....	49
Structure.....	50	U	
Symbols on the packaging.....	60	Unpacking.....	61
T			
Transport inspection.....	61		

Manufacturers declaration

Hersteller / manufacturer: HAINBUCH GmbH Spannende Technik
Erdmannhäuser Straße 57
71672 Marbach
Deutschland

Produktbezeichnung /
product denomination: **SPANNTOP [nova]**

Der Hersteller bescheinigt, dass das oben genannte Produkt bei bestimmungsgemäßer Verwendung und unter Beachtung der Betriebsanleitung und der Warnhinweise am Produkt sicher im Sinne der nationalen Vorschriften ist und /

The manufacturer certifies that the above-mentioned product is safe in the sense of national regulations when used as intended and in compliance with the operating instructions and warnings on the product:

- eine Risikobeurteilung durchgeführt wurde in Anlehnung an /
a risk assessment was carried out on the basis of
EN ISO 12100:2011-03 Sicherheit von Maschinen – Allgemeine Gestaltungs-
leitsätze / Safety of Machinery – Basic concepts
- Nationale und europäische Normen einhält / it complies with national and european standards:
DIN EN 1550:1997 Sicherheitsanforderungen für die Gestaltung und
Konstruktion von Spannfuttern für die Werkstück-
aufnahme /
Safety requirements for the design and construction
of work holding chucks
- eine Betriebsanleitung in inhaltlicher Anlehnung an Maschinenrichtlinie Anhang I Nr. 1.7.4.2. und in inhaltlicher Anlehnung an die Bestimmungen des Anhang VI der Maschinenrichtlinie zur Montageanleitung erstellt wurde /
an operation manual has been created in accordance with the contents of machinery directive annex I No. 1.7.4.2 and in accordance with the regulations of annex VI of the machinery directive for the assembly instructions
- Kennzeichnungen in Anlehnung an EN 1550 Abschnitt 6.3.1 oder ISO 16156 Abschnitt 6.3. vorgenommen wurden. Es wurden dabei die Vorgaben in Anlehnung an Anhang I Nr. 1.7.3. der Maschinenrichtlinie eingehalten /
markings have been made in accordance with EN 1550 Section 6.3.1 or ISO 16167 Section 6.3. The specifications in accordance with annex I No. 1.7.3 of the machinery directive were complied with.



HAINBUCH GMBH · SPANNENDE TECHNIK

PO Box 1262 · 71667 Marbach / Erdmannhauser Strasse 57 · 71672 Marbach · Germany

Phone +49 7144.907-0 · Fax +49 7144.18826 · sales@hainbuch.de · www.hainbuch.com

24h-Emergency call +49 7144.907-444